

GE Consumer & Industrial  
Electrical Distribution

# AF-650 GP™ General Purpose Drive (230V to 50HP, 460/575V to 100HP)

## Operating Instructions



imagination at work



## Contents

<b>1 How to Read these Operating Instructions</b>	3
Approvals	3
Symbols	4
Abbreviations	4
<b>2 Safety Instructions and General Warning</b>	5
High Voltage	5
Avoid Unintended Start	7
Safe Stop of AF-650 GP	7
Safe Stop Installation	8
IT Mains	8
<b>3 How to Install</b>	9
Mechanical Installation	14
Electrical Installation	16
Connection to Mains and Earthing	17
Motor Connection	19
Fuses	22
Electrical Installation, Control Terminals	26
Connection Examples	27
Electrical Installation, Control Cables	28
Switches S201, S202, and S801	31
Additional Connections	34
Mechanical Brake Control	34
Motor Thermal Protection	34
How to Connect a PC to the frequency converter	35
The AF-650 GP PC Software	35
<b>4 How to Program</b>	37
The Graphical Keypad	37
How to Program on the Graphical Keypad	37
Quick Setup Parameter List	39
Parameter Lists	46
K-## Keypad Set-up	47
F-## Fundamental Parameters	48
E-## Digital In/Outs	49
C-## Frequency Control Functions	51
P-## Motor Data	52
H-## High Perf Parameters	53
AN-## Analog In / Out	55
SP-## Special Functions	56



O-## Options/Comms	57
DN-## DevicNet	58
PB-## Profibus	59
ID-## Drive Information	60
DR-## Data Readouts	62
LC-## Logic Controller	64
B-## Braking Functions	65
PI-## PID Controls	66
EC-## Feedback Option	67
RS-## Resolver Interface	68
<b>5 General Specifications</b>	<b>69</b>
Electrical Data - 200-240 V	69
Electrical Data - 380-500 V	71
Electrical Data - 525-600 V	74
<b>6 Troubleshooting</b>	<b>83</b>
Warnings/Alarm Messages	83
<b>Index</b>	<b>90</b>



# 1 How to Read these Operating Instructions

1

## 1.1.1 How to Read these Operating Instructions

AF-650 GP is designed to provide high shaft performance on electrical motors. Please read this manual carefully for proper use. Incorrect handling of the frequency converter may cause improper operation of the frequency converter or related equipment, shorten lifetime or cause other troubles.

These Operating Instructions will help you get started, install, program, and troubleshoot your AF-650 GP.

. AF-650 GP is a high performance frequency converter for asynchronous as well as permanent motors and handles various kinds of motor control principles such as volts/hertz, advanced vector control, sensorless vector, and full flux vector control.

Chapter 1, **How to Read these Operating Instructions**, introduces the manual and informs you about the approvals, symbols, and abbreviations used in this literature.

Chapter 2, **Safety Instructions and General Warnings**, entails instructions on how to handle the AF-650 GP correctly.

Chapter 3, **How to Install**, guides you through mechanical and technical installation.

Chapter 4, **How to Program**, shows you how to operate and program the AF-650 GP via the Keypad.

Chapter 5, **General Specifications**, contains technical data about AF-650 GP.

Chapter 6, **Troubleshooting**, assists you in solving problems that may occur when using AF-650 GP.

### Available Literature for AF-650 GP

- The AF-650 GP Design Guide entails all technical information about the drive design and applications including encoder, resolver and relay options.
- The AF-650 GP Profibus Operating Instructions provide the information required for controlling, monitoring and programming the drive via a Profibus network.
- The AF-650 GP DeviceNet Operating Instructions provide the information required for controlling, monitoring and programming the drive via a DeviceNet network.
- The AF-650 GP DCT 10 Operating Instructions provide information for installation and use of the software on a PC.
- The AF-650 GP IP21 / Nema 1 kit Instruction provides information for installing the IP21 / Nema 1 field installed option kits..
- The AF-650 GP 24 V DC Backup Instruction provides information for installing the 24 V DC Backup option.

GE technical literature is also available online at [www.geelectrical/drives](http://www.geelectrical/drives).

## 1.1.2 Approvals





### 1.1.3 Symbols

Symbols used in this Operating Instructions.

**NB!**

Indicates something to be noted by the reader.



Indicates a general warning.



Indicates a high-voltage warning.

\*

Indicates default setting

### 1.1.4 Abbreviations

Alternating current	AC
American wire gauge	AWG
Ampere/AMP	A
Current limit	I <sub>LIM</sub>
Degrees Celsius	°C
Direct current	DC
Drive Control Tool PC Software	DCT 10
Drive Dependent	D-TYPE
Electro Magnetic Compatibility	EMC
Electronic Thermal Overload	Elec. OL
Gram	g
Hertz	Hz
Kilohertz	kHz
Meter	m
Millihenry Inductance	mH
Milliampere	mA
Millisecond	ms
Minute	min
Nanofarad	nF
Newton Meters	Nm
Nominal motor current	I <sub>M,N</sub>
Nominal motor frequency	f <sub>M,N</sub>
Nominal motor power	P <sub>M,N</sub>
Nominal motor voltage	U <sub>M,N</sub>
Parameter	par.
Protective Extra Low Voltage	PELV
Printed Circuit Board	PCB
Rated Inverter Output Current	I <sub>INV</sub>
Revolutions Per Minute	RPM
Regenerative terminals	Regen
Second	s
Synchronous Motor Speed	n <sub>s</sub>
Torque limit	T <sub>LIM</sub>
Volts	V



## 2 Safety Instructions and General Warning

2



Equipment containing electrical components may not be disposed of together with domestic waste.  
It must be separately collected with electrical and electronic waste according to local and currently valid legislation.



The DC link capacitors remain charged after power has been disconnected. To avoid electrical shock hazard, disconnect the frequency converter from mains before carrying out maintenance. When using a PM-motor, make sure it is disconnected. Before doing service on the frequency converter wait at least the amount of time indicated below:

380 - 500 V	0.25 - 7.5 kW	4 minutes
	11 - 75 kW	15 minutes
	90 - 200 kW	20 minutes
	250 - 800 kW	40 minutes
525 - 690 V	37 - 315 kW	20 minutes
	355 - 1000 kW	30 minutes

AF-650 GP

Operating Instructions

Software version: 4.9x



These Operating Instructions can be used for all AF-650 GP frequency converters with software version 4.9x.

The software version number can be seen from par. ID-43 Software Version.

### 2.1.1 High Voltage



The voltage of the frequency converter is dangerous whenever the frequency converter is connected to mains. Incorrect installation or operation of the motor or frequency converter may cause damage to the equipment, serious personal injury or death. The instructions in this manual must consequently be observed, as well as applicable local and national rules and safety regulations.

**Installation in high altitudes**

380 - 500 V: At altitudes above 3 km, please contact GE regarding PELV.  
525 - 690 V: At altitudes above 2 km, please contact GE regarding PELV.



The voltage of the frequency converter is dangerous whenever connected to mains. Incorrect installation of the motor, frequency converter or network may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

**Safety Regulations**

1. The mains supply to the frequency converter must be disconnected whenever repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has elapsed before removing motor and mains supply plugs.
2. The [OFF] button on the control panel of the frequency converter does not disconnect the mains supply and consequently it must not be used as a safety switch.
3. The equipment must be properly earthed, the user must be protected against supply voltage and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage current exceeds 3.5 mA.
5. Protection against motor overload is not included in the factory setting. If this function is desired, set par. F-10 *Electronic Overload* to data value Elec. OL trip 1 [4] or data value Elec. OL warning 1 [3].
6. Do not remove the plugs for the motor and mains supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has elapsed before removing motor and mains plugs.
7. Please note that the frequency converter has more voltage sources than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) or external 24 V DC are installed. Check that all voltage sources have been disconnected and that the necessary time has elapsed before commencing repair work.

### 2.1.2 General Warning

**Warning:**

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected, such as load-sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

Using AF-650 GP: wait at least 15 minutes.

Shorter time is allowed only if indicated on the nameplate for the specific unit.

**Leakage Current**

The earth leakage current from the frequency converter exceeds 3.5 mA. To ensure that the earth cable has a good mechanical connection to the earth connection (terminal 95), the cable cross section must be at least 10 mm<sup>2</sup> or 2 times rated earth wires terminated separately.

**Residual Current Device**

This product can cause a D.C. current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product.

Protective earthing of the AF-650 GP and the use of RCD's must always follow national and local regulations.

**NB!**

For vertical lifting or hoisting applications it is strongly recommended to ensure that the load can be stopped in case of an emergency or a malfunction of a single part such as a contactor, etc.

If the frequency converter is in alarm mode or in an over voltage situation, the mechanical brake cuts in.



### 2.1.3 Before Commencing Repair Work

1. Disconnect the frequency converter from mains
2. Disconnect DC bus terminals 88 and 89 from load share applications
3. Wait for discharge of the DC-link. See period of time on the warning label
4. Remove motor cable

### 2.1.4 Avoid Unintended Start

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the Keypad.

- Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start.
- To avoid unintended start, always activate the [OFF] key before changing parameters.
- An electronic fault, temporary overload, a fault in the mains supply, or lost motor connection may cause a stopped motor to start. Frequency converter with Safe Stop provides protection against unintended start, if the Safe Stop Terminal 37 is on low voltage level or disconnected.

### 2.1.5 Safe Stop of AF-650 GP

The AF-650 GP can perform the safety function *Safe Torque Off* (As defined by IEC 61800-5-2) or *Stop Category 0* (as defined in EN 60204-1).

It is designed and approved suitable for the requirements of Safety Category 3 in EN 954-1. This functionality is called Safe Stop. Prior to integration and use of Safe Stop in an installation, a thorough risk analysis on the installation must be carried out in order to determine whether the Safe Stop functionality and safety category are appropriate and sufficient. In order to install and use the Safe Stop function in accordance with the requirements of Safety Category 3 in EN 954-1, the related information and instructions of the AF-650 GP Design Guide must be followed! The information and instructions of the Operating Instructions are not sufficient for a correct and safe use of the Safe Stop functionality!



### 2.1.6 Safe Stop Installation

To carry out an installation of a Category 0 Stop (EN60204) in conformance with Safety Category 3 (EN954-1), follow these instructions:

1. The bridge (jumper) between Terminal 37 and 24 V DC must be removed. Cutting or breaking the jumper is not sufficient. Remove it entirely to avoid short-circuiting. See jumper on illustration.
2. Connect terminal 37 to 24 V DC by a short-circuit protected cable. The 24 V DC voltage supply must be interruptible by an EN954-1 Category 3 circuit interrupt device. If the interrupt device and the frequency converter are placed in the same installation panel, you can use a regular cable instead of a protected one.
3. The Safe Stop function only fulfills EN 954-1 Category 3 if it is protected by a Nema 12 or Nema 4 drive. Open Chassis or Nema 1 drives must be mounted in a Nema 12 or higher cabinet to meet protection requirements for the Safe Stop functionality.




Illustration 2.1: Bridge jumper between terminal 37 and 24 VDC

The illustration below shows a Stopping Category 0 (EN 60204-1) with safety Category 3 (EN 954-1). The circuit interrupt is caused by an opening door contact. The illustration also shows how to connect a non-safety related hardware coast.




Illustration 2.2: Illustration of the essential aspects of an installation to achieve a Stopping Category 0 (EN 60204-1) with safety Category 3 (EN 954-1).

### 2.1.7 IT Mains

par. SP-50 RFI Filter can be used to disable the factory installed A1/B1 RFI filter option. If this is done it will reduce the RFI performance to A2 level. For the 525 - 690 V frequency converters, par. SP-50 RFI Filter is not available as there is no A1/B1 Factory Installed RFI Filter option.



## 3 How to Install

### 3.1.1 About How to Install

This chapter covers mechanical and electrical installations to and from power terminals and control card terminals. Electrical installation of *options* is described in the relevant Operating Instructions and Design Guide.

3

### 3.1.2 How to Get Started

AF-650 GP is designed to achieve a quick installation by following the steps described below.



Read the safety instructions before installing the unit.

#### Mechanical Installation

- Mechanical mounting

#### Electrical Installation

- Connection to Mains and Protecting Earth
- Motor connection and cables
- Fuses and circuit breakers
- Control terminals - cables

#### Quick setup

- Keypad
- Auto Tuning of drive
- Programming




Illustration 3.1: Diagram showing basic installation including mains, motor, start/stop key, and potentiometer for speed adjustment.



3

12/13




130BA809.10

15



130BA811.10

**Unit Sizes****12**  
0.25-3 kW  
(200-240 V)  
0.37-4.0 kW  
(380-480/ 500 V)  
0.75-4 kW  
(525-600 V)**13**  
3.7 kW  
(200-240 V)  
5.5-7.5 kW  
(380-480/ 500 V)  
5.5-7.5 kW  
(525-600 V)**15**  
0.25-3.7 kW  
(200-240 V)  
0.37-7.5 kW  
(380-480/ 500 V)  
0.75-7.5 kW  
(525-600 V)**IP**

20 Chassis

20 Chassis

55/66 Nema 12/Nema 4

**NEMA**

Nema 1

Nema 1

**Height**

Height of back plate

A

268 mm

375 mm

268 mm

375 mm

420 mm

Height with de-coupling plate

A

374 mm

374 mm

-

-

Distance between mounting holes

a

257 mm

350 mm

257 mm

350 mm

402 mm

**Width**

Width of back plate

B

90 mm

90 mm

130 mm

130 mm

242 mm

Width of back plate with one C option

B

130 mm

130 mm

170 mm

170 mm

242 mm

Width of back plate with two C options

B

150 mm

150 mm

190 mm

190 mm

242 mm

Distance between mounting holes

b

70 mm

70 mm

110 mm

110 mm

215 mm

**Depth**

Depth without option A/B

C

205 mm

207 mm

205 mm

207 mm

195 mm

With option A/B

C

220 mm

222 mm

220 mm

222 mm

195 mm

**Screw holes**

c

8.0 mm

8.0 mm

8.0 mm

8.0 mm

8.25 mm

d

ø11 mm

ø11 mm

ø11 mm

ø11 mm

ø12 mm

e

ø5.5 mm

ø5.5 mm

ø5.5 mm

ø5.5 mm

ø6.5 mm

f

9 mm

9 mm

9 mm

9 mm

9 mm

**Max weight**

4.9 kg

5.3 kg


6.6 kg

7.0 kg

13.5/14.2 kg



## Mechanical Dimensions, 2X Unit Sizes




3

Unit Sizes	21	22	23	24
5.5-7.5 kW (200-240 V)	11 kW (200-240 V)	5.5-7.5 kW (200-240 V)	11-15 kW (200-240 V)	11-15 kW (200-240 V)
11-15 kW (380-480/500 V)	18.5-22 kW (380-480/ 500 V)	11-15 kW (380-480/500 V)	18.5-30 kW (380-480/ 500 V)	18.5-30 kW (380-480/ 500 V)
11-15 kW (525-600 V)	18.5-22 kW (525-600 V)	11-15 kW (525-600 V)	18.5-30 kW (525-600 V)	18.5-30 kW (525-600 V)
IP 21/ 55/66	55/66	20	20	20
NEMA Nema 1/Nema 12	Nema 12/Nema 4	Chassis	Chassis	
Height				
Height of back plate	A	480 mm	650 mm	399 mm
Height with decoupling plate	A	-	-	420 mm
Distance between mounting holes	a	454 mm	624 mm	380 mm
Width				
Width of back plate	B	242 mm	242 mm	165 mm
Width of back plate with one C option	B	242 mm	242 mm	205 mm
Width of back plate with two C options	B	242 mm	242 mm	225 mm
Distance between mounting holes	b	210 mm	210 mm	140 mm
Depth				
Depth without option A/B	C	260 mm	260 mm	249 mm
With option A/B	C	260 mm	260 mm	262 mm
Screw holes				
c	12 mm	12 mm	8 mm	
d	ø19 mm	ø19 mm	12 mm	
e	ø9 mm	ø9 mm	6.8 mm	8.5 mm
f	9 mm	9 mm	7.9 mm	15 mm
Max weight	23 kg	27 kg	12 kg	23.5 kg



## Mechanical Dimensions, 3X Unit Sizes


3



Unit Sizes	31	32	33	34
15-22 kW (200-240 V)	30-37 kW (200-240 V)	18.5-22 kW (200-240 V)	30-37 kW (200-240 V)	
30-45 kW (380-480/ 500 V)	55-75 kW (380-480/ 500 V)	37-45 kW (380-480/ 500 V)	55-75 kW (380-480/ 500 V)	
30-45 kW (525-600 V)	55-90 kW (525-600 V)	37-45 kW (525-600 V)	55-90 kW (525-600 V)	
IP	55/66	55/66	20	20
NEMA	Nema 12/Nema 4	Nema 12/Nema 4	Chassis	Chassis
Height				
Height of back plate	A	680 mm	770 mm	550 mm
Height with de-coupling plate	A			630 mm
Distance between mounting holes	a	648 mm	739 mm	521 mm
Width				
Width of back plate	B	308 mm	370 mm	308 mm
Width of back plate with one C option	B	308 mm	370 mm	308 mm
Width of back plate with two C options	B	308 mm	370 mm	308 mm
Distance between mounting holes	b	272 mm	334 mm	270 mm
Depth				
Depth without option A/B	C	310 mm	335 mm	333 mm
With option A/B	C	310 mm	335 mm	333 mm
Screw holes				
c	12.5 mm	12.5 mm		
d	ø19 mm	ø19 mm		
e	ø9 mm	ø9 mm	8.5 mm	8.5 mm
f	9.8 mm	9.8 mm	17 mm	17 mm
<b>Max weight</b>	45 kg	65 kg	35 kg	50 kg



Accessory Bags: Find the following parts included in the frequency converter accessory bags




Unit Sizes 22 and 23, IP20 Open Chassis




Unit Size 15, Nema 12 or Nema 4




Unit Sizes 21 and 22  
IP55/Type 12




Unit Size 23, IP20 Open Chassis




Unit Size 24, IP20 Open Chassis



Unit Sizes 31 and 32, IP55/Nema 12, IP66/Nema 4



Unit Size 23, IP20 Open Chassis



Unit Size 24, IP20 Open Chassis

1 + 2 only available in units with brake chopper. For DC link connection (Load sharing) the connector 1 can be ordered separately



## 3.2 Mechanical Installation

### 3.2.1 Mechanical mounting

All IP20.

3

If the P21/Nema 1 field installed option kits are installed, there must be a clearance of a minimum of 50mm or 2 inches between drives.

Air passage for different Unit Sizes											
Unit Size:	12	13	15	21	22	23	24	31	32	33	34
a (mm):	100	100	100	200	200	200	200	200	225	200	225
b (mm):	100	100	100	200	200	200	200	200	225	200	225

Table 3.1:

1. Drill holes in accordance with the measurements given.
2. You must provide screws suitable for the surface on which you want to mount the frequency converter. Retighten all four screws.




Table 3.2: Mounting Unit Sizes 15, 21, 22, 23, 24, 31, 32, 33 and 34 on a non-solid back wall, the drive must be provided with a back plate A due to insufficient cooling air over the heat sink.



### 3.2.2 Panel Through Mounting

A Panel Through Mount Kit is available for frequency converter series AF-600 FP, .

In order to increase heatsink cooling and reduce panel depth, the frequency converter may be mounted in a through panel. Furthermore the in-built fan can then be removed.

The kit is available for Unit Sizes 15 through 32 (230V, 1/3 to 50HP and 460V/575V 1/2 to 100HP) .

3

**NB!**

This kit cannot be used with cast front covers. No cover or imminent plastic cover must be used instead.

For more information please contact GE.



### 3.3 Electrical Installation

NB!

**Cables General**

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. Copper (60/75°C) conductors are recommended.

**3**

**Aluminium Conductors**

Terminals can accept aluminium conductors but the conductor surface has to be clean and the oxidation must be removed and sealed by neutral acid-free Vaseline grease before the conductor is connected.

Furthermore the terminal screw must be retightened after two days due to softness of the aluminium. It is crucial to keep the connection a gas tight joint, otherwise the aluminium surface will oxidize again.

Tightening-up Torque					
Unit Size	200 - 240 V	380 - 500 V	525 - 690 V	Cable for:	Tightening up torque
11	0.25-1.5 kW	0.37-1.5 kW	-	Mains, Brake resistor, load sharing, Motor cables	0.5-0.6 Nm
12	0.25-2.2 kW	0.37-4 kW	0.75-4 kW		
13	3-3.7 kW	5.5-7.5 kW	5.5-7.5 kW		
15	3-3.7 kW	5.5-7.5 kW	0.75-7.5 kW		
21	5.5-7.5 kW	11-15 kW	-	Mains, Brake resistor, load sharing, Motor cables	1.8 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
22	11 kW	18.5-22 kW	-	Mains, Brake resistor, load sharing cables	4.5 Nm
				Motor cables	4.5 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
23	5.5-7.5 kW	11-15 kW	-	Mains, Brake resistor, load sharing, Motor cables	1.8 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
24	11-15 kW	18.5-30 kW	-	Mains, Brake resistor, load sharing, Motor cables	4.5 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
31	15-22 kW	30-45 kW	-	Mains, Brake resistor, load sharing cables	10 Nm
				Motor cables	10 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
32	30-37 kW	55-75 kW	-	Mains, motor cables	14 Nm (up to 95 mm <sup>2</sup> ) 24 Nm (over 95 mm <sup>2</sup> )
				Load Sharing, brake cables	14 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
33	18.5-22 kW	30-37 kW	-	Mains, Brake resistor, load sharing, Motor cables	10 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm
34	37-45 kW	55-75 kW	-	Mains, motor cables	14 Nm (up to 95 mm <sup>2</sup> ) 24 Nm (over 95 mm <sup>2</sup> )
				Load Sharing, brake cables	14 Nm
				Relay	0.5-0.6 Nm
				Earth	2-3 Nm

#### 3.3.1 Removal of Knockouts for Extra Cables

1. Remove cable entry from the frequency converter (Avoiding foreign parts falling into the frequency converter when removing knockouts)
2. Cable entry has to be supported around the knockout you intend to remove.
3. The knockout can now be removed with a strong mandrel and a hammer.
4. Remove burrs from the hole.
5. Mount Cable entry on frequency converter.



### 3.3.2 Connection to Mains and Earthing

**NB!**

The plug connector for power is plugable on frequency converters up to 7.5 kW.

1. Fit the two screws in the de-coupling plate, slide it into place and tighten the screws.
2. Make sure the frequency converter is properly earthed. Connect to earth connection (terminal 95). Use screw from the accessory bag.
3. Place plug connector 91(L1), 92(L2), 93(L3) from the accessory bag onto the terminals labelled MAINS at the bottom of the frequency converter.
4. Attach mains wires to the mains plug connector.
5. Support the cable with the supporting enclosed brackets.

**3****NB!**

Check that mains voltage corresponds to the mains voltage of the name plate.


**IT Mains**

Do not connect 400 V frequency converters with RFI-filters to mains supplies with a voltage between phase and earth of more than 440 V.




The earth connection cable cross section must be at least 10 mm<sup>2</sup> or 2 x rated mains wires terminated separately according to EN 50178.

The mains connection is fitted to the mains switch if this is included.

**Mains connection for Unit Sizes 12 and 13 IP20 Open Chassis drive types**

(230V to 5HP, 460V/575V to 10HP):





Mains connector (IP 55/66)Unit Size 15 Nema 12 or Nema 4 drive types  
(230V to 5HP, 460V/575V to 10HP)

3





Illustration 3.2: Mains connection for unit sizes 21 and 22 Nema 12 or Nema 4 drive types (230V, 7.5 to 15HP, 460V/575V, 15 to 30HP).




Illustration 3.3: Mains connection for unit size 23 IP20 Open Chassis drive type (230V, 7.5 to 10HP, 460V/575V, 15 to 25HP).




Illustration 3.4: Mains connection for unit size 24 IP20 Open Chassis drive type (230V, 15 to 20HP, 460V/575V, 25 to 40HP).




Illustration 3.5: Mains connection for unit sizes 31 and 32 Nema 12 or Nema 4 drive types (230V, 20 to 50HP, 460V, 40 to 100HP, 575V, 40 to 125HP).




Illustration 3.6: Mains connection for unit size 33 IP20 Open Chassis drive type (230V, 25 to 30HP, 460V/575V, 50 to 60HP).




Illustration 3.7: Mains connection for unit size 34 IP20 Open Chassis drive type (230V, 40 to 50HP, 460V, 75 to 100HP, 575V, 75 to 125HP).

3

### 3.3.3 Motor Connection

**NB!**

Use a screened/armoured motor cable to comply with EMC emission specifications. For more information, see *EMC Test Results*.

See section General Specifications for correct dimensioning of motor cable cross-section and length.

**Screening of cables:** Avoid installation with twisted screen ends (pigtails). If it is necessary to break the screen to install a motor isolator or motor contactor, the screen must be continued at the lowest possible HF impedance.

Connect the motor cable screen to both the decoupling plate of the frequency converter and to the metal housing of the motor.

Make the screen connections with the largest possible surface area (cable clamp). This is done by using the supplied installation devices in the frequency converter.

If it is necessary to split the screen to install a motor isolator or motor relay, the screen must be continued with the lowest possible HF impedance.

**Cable-length and cross-section:** The frequency converter has been tested with a given length of cable and a given cross-section of that cable. If the cross-section is increased, the cable capacitance - and thus the leakage current - may increase, and the cable length must be reduced correspondingly. Keep the motor cable as short as possible to reduce the noise level and leakage currents.

**Switching frequency:** When frequency converters are used together with Sine-wave filters to reduce the acoustic noise from a motor, the switching frequency must be set according to the Sine-wave filter instruction in par. F-26 Motor Noise (*Carrier Freq*).

1. Fasten decoupling plate to the bottom of the frequency converter with screws and washers from the accessory bag.
2. Attach motor cable to terminals 96 (U), 97 (V), 98 (W).
3. Connect to earth connection (terminal 99) on decoupling plate with screws from the accessory bag.
4. Insert plug connectors 96 (U), 97 (V), 98 (W) (up to 7.5 kW) and motor cable to terminals labelled MOTOR.
5. Fasten screened cable to decoupling plate with screws and washers from the accessory bag.

All types of three-phase asynchronous standard motors can be connected to the frequency converter. Normally, small motors are star-connected (230/400 V, Y). Large motors are normally delta-connected (400/690 V, Δ). Refer to the motor name plate for correct connection mode and voltage.



3




Illustration 3.8: Motor connection for units sizes 12 and 13 IP20 Open Chassis drive types (230V to 5HP, 460V/575V to 10HP)




Illustration 3.9: Motor connection for unit size 15 Nema 12 or Nema 4 drive types (230V to 5HP, 460V/575V to 10HP)




Illustration 3.10: Motor connection for unit sizes 21 and 22 Nema 12 or Nema 4 drive types (230V, 7.5 to 15HP, 460V/575V, 15 to 30HP)




Illustration 3.11: Motor connection for unit size 23 IP20 Open Chassis drive type (230V, 7.5 to 10HP, 460V/575V, 15 to 25HP).




Illustration 3.12: Motor connection for unit size 24 IP20 Open Chassis drive type (230V, 15 to 20HP, 460V/575V, 25 to 40HP).





Illustration 3.13: Motor connection for unit sizes 31 and 32 Nema 12 or Nema 4 drive types (230V, 20 to 50HP, 460V, 40 to 100HP, 575V, 50 to 125HP)



3

Illustration 3.14: Motor connection for unit sizes 33 and 34 IP20 Open Chassis drive types (230V, 25 to 50HP, 460V, 50 to 100HP, 575V, 50 to 125HP).




Illustration 3.15: Cable entry holes for unit size 21. The suggested use of the holes are purely recommendations and other solutions are possible.




Illustration 3.17: Cable entry holes for unit size 31. The suggested use of the holes are purely recommendations and other solutions are possible.




Illustration 3.16: Cable entry holes for unit size 22. The suggested use of the holes are purely recommendations and other solutions are possible.





Illustration 3.18: Cable entry holes for unit size 32. The suggested use of the holes are purely recommendations and other solutions are possible.

Term. no.	96	97	98	99	
	U	V	W	PE <sup>1)</sup>	Motor voltage 0-100% of mains voltage. 3 wires out of motor
	U1 W2	V1 U2	W1 V2	PE <sup>1)</sup>	Delta-connected 6 wires out of motor
	U1	V1	W1	PE <sup>1)</sup>	Star-connected U2, V2, W2 U2, V2 and W2 to be interconnected separately.

<sup>1)</sup>Protected Earth Connection



### 3.3.4 Fuses

#### Branch circuit protection:

In order to protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be short-circuited and overcurrent protected according to national/international regulations.

#### Short-circuit protection:

The frequency converter must be protected against short-circuit to avoid electrical or fire hazard. GE recommends using the fuses mentioned below to protect service personnel and equipment in case of an internal failure in the drive. The frequency converter provides full short-circuit protection in case of a short-circuit on the motor output.

#### Overcurrent protection:

Provide overload protection to avoid fire hazard due to overheating of the cables in the installation. Fuses or circuit breakers can be used to provide the overcurrent protection in the installation. Overcurrent protection must always be carried out according to national regulations.

The AF-650 GP drive is suitable in a circuit capable of supplying a maximum of 100,000 A<sub>rms</sub> (symmetrical), 500 V maximum.

#### Non UL compliance

If UL/cUL is not to be complied with, we recommend using the following fuses, which will ensure compliance with EN50178:

In case of malfunction, not following the recommendation may result in unnecessary damage to the frequency converter.

AF-650 GP	Max. fuse size <sup>1)</sup>	Voltage	Type
1/3 to 1 HP	10A	200-240 V	type gG
2 to 3 HP	20A	200-240 V	type gG
5 HP	32A	200-240 V	type gG
7.5 to 10 HP	63A	380-500 V	type gG
15 HP	80A	380-500 V	type gG
20 to 25 HP	125A	380-500 V	type gG
30 HP	160A	380-500 V	type aR
40 HP	200A	380-500 V	type aR
50 HP	250A	380-500 V	type aR

1) Max. fuses - refer to national/international regulations to select an appropriate fuse size.

AF-650 GP	Max. fuse size <sup>1)</sup>	Voltage	Type
3 to 5 HP	10A	380-500 V	type gG
3 to 5 HP	20A	380-500 V	type gG
7.5 to 10 HP	32A	380-500 V	type gG
15 to 25 HP	63A	380-500 V	type gG
30 HP	80A	380-500 V	type gG
40 HP	100A	380-500 V	type gG
50 HP	125A	380-500 V	type gG
60 HP	160A	380-500 V	type aR
75 to 100 HP	250A	380-500 V	type aR



## UL Compliance

200-240 V

AF-650 GP	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann
HP	Type RK1	Type J	Type T	Type CC	Type CC	Type CC
1/3 to 1/2 HP	KTN-R05	JKS-05	JJN-06	FNQ-R-5	KTK-R-5	LP-CC-5
1 HP	KTN-R10	JKS-10	JJN-10	FNQ-R-10	KTK-R-10	LP-CC-10
2 HP	KTN-R15	JKS-15	JJN-15	FNQ-R-15	KTK-R-15	LP-CC-15
3 HP	KTN-R20	JKS-20	JJN-20	FNQ-R-20	KTK-R-20	LP-CC-20
5 HP	KTN-R30	JKS-30	JJN-30	FNQ-R-30	KTK-R-30	LP-CC-30
7.5 HP	KTN-R50	KS-50	JJN-50	-	-	-
10 HP	KTN-R60	JKS-60	JJN-60	-	-	-
15 HP	KTN-R80	JKS-80	JJN-80	-	-	-
20 to 25 HP	KTN-R125	JKS-150	JJN-125	-	-	-

3

AF-650 GP	SIBA	Littel fuse	Ferraz-Shawmut	Ferraz-Shawmut
HP	Type RK1	Type RK1	Type CC	Type RK1
1/3 to 1/2 HP	5017906-005	KLN-R05	ATM-R05	A2K-05R
1 HP	5017906-010	KLN-R10	ATM-R10	A2K-10R
2 HP	5017906-016	KLN-R15	ATM-R15	A2K-15R
3 HP	5017906-020	KLN-R20	ATM-R20	A2K-20R
5 HP	5012406-032	KLN-R30	ATM-R30	A2K-30R
7.5 HP	5014006-050	KLN-R50	-	A2K-50R
10 HP	5014006-063	KLN-R60	-	A2K-60R
15 HP	5014006-080	KLN-R80	-	A2K-80R
20 to 25 HP	2028220-125	KLN-R125	-	A2K-125R

AF-650 GP	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut
HP	Type JFHR2	Type RK1	JFHR2	JFHR2
30 HP	FWX-150	2028220-150	L25S-150	A25X-150
40 HP	FWX-200	2028220-200	L25S-200	A25X-200
50 HP	FWX-250	2028220-250	L25S-250	A25X-250

KTS-fuses from Bussmann may substitute KTN for 240 V frequency converters.

FWH-fuses from Bussmann may substitute FWX for 240 V frequency converters.

KLSR fuses from LITTEL FUSE may substitute KLN fuses for 240 V frequency converters.

L50S fuses from LITTEL FUSE may substitute L50S fuses for 240 V frequency converters.

A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V frequency converters.

A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V frequency converters.

## 380-500 V

AF-650 GP	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann
HP	Type RK1	Type J	Type T	Type CC	Type CC	Type CC
1/2 to 1 HP	KTS-R6	JKS-6	JJS-6	FNQ-R-6	KTK-R-6	LP-CC-6
2 to 3 HP	KTS-R10	JKS-10	JJS-10	FNQ-R-10	KTK-R-10	LP-CC-10
5 HP	KTS-R20	JKS-20	JJS-20	FNQ-R-20	KTK-R-20	LP-CC-20
7.5 HP	KTS-R25	JKS-25	JJS-25	FNQ-R-25	KTK-R-25	LP-CC-25
10 HP	KTS-R30	JKS-30	JJS-30	FNQ-R-30	KTK-R-30	LP-CC-30
15 HP	KTS-R40	JKS-40	JJS-40	-	-	-
20 HP	KTS-R50	JKS-50	JJS-50	-	-	-
25 HP	KTS-R60	JKS-60	JJS-60	-	-	-
30 HP	KTS-R80	JKS-80	JJS-80	-	-	-
40 HP	KTS-R100	JKS-100	JJS-100	-	-	-
50 HP	KTS-R125	JKS-150	JJS-150	-	-	-
60 HP	KTS-R150	JKS-150	JJS-150	-	-	-



AF-650 GP	SIBA	Littel fuse	Ferraz-Shawmut	Ferraz-Shawmut
HP	Type RK1	Type RK1	Type CC	Type RK1
1/2 to 1 HP	5017906-006	KLS-R6	ATM-R6	A6K-6R
2 to 3 HP	5017906-010	KLS-R10	ATM-R10	A6K-10R
5 HP	5017906-020	KLS-R20	ATM-R20	A6K-20R
7.5 HP	5017906-025	KLS-R25	ATM-R25	A6K-25R
10 HP	5012406-032	KLS-R30	ATM-R30	A6K-30R
15 HP	5014006-040	KLS-R40	-	A6K-40R
20 HP	5014006-050	KLS-R50	-	A6K-50R
25 HP	5014006-063	KLS-R60	-	A6K-60R
30 HP	2028220-100	KLS-R80	-	A6K-80R
40 HP	2028220-125	KLS-R100	-	A6K-100R
50 HP	2028220-125	KLS-R125	-	A6K-125R
60 HP	2028220-160	KLS-R150	-	A6K-150R

AF-650 GP	Bussmann	Bussmann	Bussmann	Bussmann
HP	JFHR2	Type H	Type T	JFHR2
75 HP	FWH-200	-	-	-
100 HP	FWH-250	-	-	-

AF-650 GP	SIBA	Littel fuse	Ferraz-Shawmut	Ferraz-Shawmut
HP	Type RK1	JFHR2	JFHR2	JFHR2
75 HP	2028220-200	L50S-225	-	A50-P225
100 HP	2028220-250	L50S-250	-	A50-P250

Ferraz-Shawmut A50QS fuses may be substituted for A50P fuses.

170M fuses shown from Bussmann use the -/80 visual indicator. -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted.

#### 550 - 600V

AF-650 GP	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann
HP	Type RK1	Type J	Type T	Type CC	Type CC	Type CC
1 to 2 HP	KTS-R-5	JKS-5	JJS-6	FNQ-R-5	KTK-R-5	LP-CC-5
3 to 5 HP	KTS-R10	JKS-10	JJS-10	FNQ-R-10	KTK-R-10	LP-CC-10
7.5 to 10 HP	KTS-R20	JKS-20	JJS-20	FNQ-R-20	KTK-R-20	LP-CC-20

AF-650 GP	SIBA	Littel fuse	Ferraz-Shawmut
HP	Type RK1	Type RK1	Type RK1
1 to 2 HP	5017906-005	KLSR005	A6K-5R
3 to 5 HP	5017906-010	KLSR010	A6K-10R
7.5 to 10 HP	5017906-020	KLSR020	A6K-20R


AF-650 GP	Bussmann	SIBA	Ferraz-Shawmut
HP	JFHR2	Type RK1	Type RK1
50 HP	170M3013	2061032.125	6.6URD30D08A0125
60 HP	170M3014	2061032.160	6.6URD30D08A0160
75 HP	170M3015	2061032.200	6.6URD30D08A0200
100 HP	170M3015	2061032.200	6.6URD30D08A0200

170M fuses shown from Bussmann use the -/80 visual indicator. -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted.



### 3.3.5 Access to Control Terminals

All terminals to the control cables are located underneath the terminal cover on the front the IP20 Open Chassis and IP20 with Nema 1 field installed kits.. Remove the terminal cover with a screwdriver.



3

Illustration 3.19: Access to control terminals for unit sizes 12, 13, 23, 24, 33, and 34

Remove front-cover of Nema 12 and Nema 4 drive types to access control terminals. When replacing the front-cover, please ensure proper fastening by applying a torque of 2 Nm.




Illustration 3.20: Access to control terminals for unit sizes 15, 21, 22, 31, and 32



### 3.3.6 Electrical Installation, Control Terminals

#### To mount the cable to the terminal:



1. Strip insulation of 9-10 mm
2. Insert a screwdriver<sup>1)</sup> in the square hole.
3. Insert the cable in the adjacent circular hole.
4. Remove the screw driver. The cable is now mounted to the terminal.

**3**

#### To remove the cable from the terminal:

1. Insert a screwdriver<sup>1)</sup> in the square hole.
2. Pull out the cable.

<sup>1)</sup> Max. 0.4 x 2.5 mm






## 3.4 Connection Examples


### 3.4.1 Start/Stop

Terminal 18 = par. E-01 Terminal 18 Digital Input [8] Start  
Terminal 27 = par. E-03 Terminal 27 Digital Input [0] No operation (Default coast inverse)  
Terminal 37 = Safe stop



### 3.4.2 Pulse Start/Stop

Terminal 18 = par. E-01 Terminal 18 Digital Input Latched start, [9]  
Terminal 27= par. E-03 Terminal 27 Digital Input Stop inverse, [6]  
Terminal 37 = Safe stop






### 3.4.3 Speed Up/Down

Terminals 29/32 = Speed up/down:


- Terminal 18 = par. E-01 Terminal 18 *Digital Input Start* [9] (default)
- Terminal 27 = par. E-03 Terminal 27 *Digital Input Freeze reference* [19]
- Terminal 29 = par. E-04 Terminal 29 *Digital Input Speed up* [21]
- Terminal 32 = par. E-05 Terminal 32 *Digital Input Speed down* [22]



### 3.4.4 Potentiometer Reference

Voltage reference via a potentiometer:

- Reference Source 1 = [1] *Analog input 53* (default)
- Terminal 53, Low Voltage = 0 Volt
- Terminal 53, High Voltage = 10 Volt
- Terminal 53, Low Ref./Feedback = 0 RPM
- Terminal 53, High Ref./Feedback = 1500 RPM
- Switch S201 = OFF (U)





## 3.5.1 Electrical Installation, Control Cables




Illustration 3.21: Diagram showing all electrical terminals without options.

Terminal 37 is the input to be used for Safe Stop. For instructions on Safe Stop installation please refer to the section *Safe Stop Installation* of the AF-650 GP Design Guide.

Very long control cables and analogue signals may in rare cases and depending on installation result in 50/60 Hz earth loops due to noise from mains supply cables.



If this occurs, it may be necessary to break the screen or insert a 100 nF capacitor between screen and chassis.

The digital and analogue inputs and outputs must be connected separately to the common inputs (terminal 20, 55, 39) of the frequency converter to avoid ground currents from both groups to affect other groups. For example, switching on the digital input may disturb the analog input signal.




## Input polarity of control terminals

3

**NB!**

Control cables must be screened/armoured.

See section entitled *Earthing of Screened/Armoured Control Cables* for the correct termination of control cables.





### 3.5.2 Switches S201, S202, and S801

Switches S201 (A53) and S202 (A54) are used to select a current (0-20 mA) or a voltage (-10 to 10 V) configuration of the analog input terminals 53 and 54 respectively.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

See drawing *Diagram showing all electrical terminals* in section *Electrical Installation*.

3

**Default setting:**


S201 (A53) = OFF (voltage input)

S202 (A54) = OFF (voltage input)

S801 (Bus termination) = OFF



When changing the function of S201, S202 or S801 be careful not to use force for the switch over. It is recommended to remove the Keypad fixture (cradle) when operating the switches. The switches must not be operated with power on the frequency converter.





### 3.6.1 Final Set-Up and Test


To test the set-up and ensure that the frequency converter is running, follow these steps.

#### Step 1. Locate the motor name plate

NB!

The motor is either star- (Y) or delta- connected ( $\Delta$ ). This information is located on the motor name plate data.

3



3 ~ MOTOR NR. 1827421 2003	
S/E005A9	
1,5	kW
n <sub>2</sub> 31,5	/min. 400 Y V
n <sub>1</sub> 1400	/min. 50 Hz
cos φ 0,80	3,6 A
1,7L	
B IP 65	H1/1A

130BT307

#### Step 2. Enter the motor name plate data in this parameter list.

To access this list first press the [QUICK MENU] key then select "Quick Setup".

Use the up and down arrow keys to navigate to the parameters associated with the motor nameplate values.

1.	par. P-07 Motor Power [kW] par. P-02 Motor Power [HP]
2.	par. F-05 Motor Rated Voltage
3.	par. F-04 Base Frequency
4.	par. P-03 Motor Current
5.	par. P-06 Base Speed

#### Step 3. Activate the Auto Tune

Performing an Auto Tune will ensure optimum performance. The Auto Tune measures the values from the motor model equivalent diagram.

1. Connect terminal 37 to terminal 12 (if terminal 37 is available).
2. Connect terminal 27 to terminal 12 or set par. E-03 Terminal 27 *Digital Input* to 'No function'.
3. Activate the Auto Tune par. P-04 Auto Tune.
4. Choose between complete or reduced Auto Tune. If a Sine-wave filter is connected, run only the reduced Auto Tune, or remove the Sine-wave filter and run complete Auto Tune..
5. Press the [OK] key. The display shows "Press [Hand] to start".
6. Press the [Hand] key. A progress bar indicates if the Auto Tune is in progress.

#### Stop the Auto Tune during operation

1. Press the [OFF] key - the frequency converter enters into alarm mode and the display shows that the Auto Tune was terminated by the user.

#### Successful Auto Tune

1. The display shows "Press [OK] to finish Auto Tune".
2. Press the [OK] key to exit the Auto Tune state.

**Unsuccessful Auto Tune**

1. The frequency converter enters into alarm mode. A description of the alarm can be found in the *Warnings and Alarms* chapter.
2. "Report Value" in the [Alarm Log] shows the last measuring sequence carried out by the Auto Tune, before the frequency converter entered alarm mode. This number along with the description of the alarm will assist you in troubleshooting. If you contact GE for service, make sure to mention number and alarm description.

**NB!**

Unsuccessful Auto Tune is often caused by incorrectly entering motor name plate data or a too big difference between the motor power size and the frequency converter power size.

**Step 4. Set speed limit and accel/decel times**

par. F-52 Minimum Reference

par. F-53 Maximum Reference

Table 3.3: Set up the desired limits for speed and ramp time.

par. F-18 Motor Speed Low Limit [RPM] or par. F-16 Motor Speed Low Limit [Hz]

par. F-17 Motor Speed High Limit [RPM] or par. F-15 Motor Speed High Limit [Hz]

par. F-07 Accel Time 1

par. F-08 Decel Time 1



## 3.7 Additional Connections

### 3.7.1 Mechanical Brake Control

In hoisting/lowering applications, it is necessary to be able to control an electro-mechanical brake:

- Control the brake using any relay output or digital output (terminal 27 or 29).
- Keep the output closed (voltage-free) as long as the frequency converter is unable to 'support' the motor, for example due to the load being too heavy.
- Select *Mechanical brake control* [32] in E-2# for applications with an electro-mechanical brake.
- The brake is released when the motor current exceeds the preset value in par. B-20 Release Brake Current.
- The brake is engaged when the output frequency is less than the frequency set in par. B-21 Activate Brake Speed [RPM] or par. B-22 Activate Brake Speed [Hz], and only if the frequency converter carries out a stop command.

If the frequency converter is in alarm mode or in an over-voltage situation, the mechanical brake immediately cuts in.

3

### 3.7.2 Parallel Connection of Motors

The frequency converter can control several parallel-connected motors. The total current consumption of the motors must not exceed the rated output current  $I_{M,N}$  for the frequency converter.

**NB!**


Installations with cables connected in a common joint as in the illustration below, is only recommended for short cable lengths.

**NB!**

When motors are connected in parallel, par. P-04 Auto Tune cannot be used.

**NB!**

The electronic thermal overload of the frequency converter cannot be used as motor protection for the individual motor in systems with parallel-connected motors. Provide further motor protection by e.g. thermistors in each motor or individual thermal relays (circuit breakers are not suitable as protection).



Problems may arise at start and at low RPM values if motor sizes are widely different because small motors' relatively high ohmic resistance in the stator calls for a higher voltage at start and at low RPM values.

### 3.7.3 Motor Thermal Protection

The electronic thermal overload in the frequency converter has received UL-approval for single motor protection, when par. F-10 *Electronic Overload* is set for *Elec. OL Trip* and par. P-03 *Motor Current* is set to the rated motor current (see motor name plate).




### 3.7.4 How to Connect a PC to the frequency converter

To control the frequency converter from a PC, install the DCT-10 Drive Control Tool Software.

The PC is connected via a standard (host/device) USB cable, or via the RS485 interface as shown in the section *Bus Connection* in the Programming Guide.

**NB!**

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals. The USB connection is connected to protection earth on the frequency converter. Use only isolated laptop as PC connection to the USB connector on the frequency converter.



130BT308

Illustration 3.22: USB connection.

### 3.7.5 The DCT-10 Drive Control Tool Software

**Data storage in PC via DCT-10 Drive Control Tool Software:**

1. Connect a PC to the unit via USB com port
2. Open DCT-10 Drive Control Tool Software
3. Select in the "network" section the USB port
4. Choose "Copy"
5. Select the "project" section
6. Choose "Paste"
7. Choose "Save as"

All parameters are now stored.

**Data transfer from PC to drive via DCT-10 Drive Control Tool Software:**

1. Connect a PC to the unit via USB com port
2. Open DCT-10 Drive Control Tool Software
3. Choose "Open" – stored files will be shown
4. Open the appropriate file
5. Choose "Write to drive"

All parameters are now transferred to the drive.

A separate manual for DCT-10 Drive Control Tool Software as part of the software.



# 4



## 4 How to Program

### 4.1 The Graphical Keypad

The easiest programming of the frequency converter is performed by the Graphical Keypad.

#### 4.1.1 How to Program on the Graphical Keypad

The following instructions are valid for the graphical Keypad:


**The keypad is divided into four functional groups:**

1. Graphical display with Status lines.
2. Menu keys and indicator lights - changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).

All data is displayed in the display, which can show up to five items of operating data while displaying [Status].

**Display lines:**

- a. Status line: Status messages displaying icons and graphic.
- b. Line 1-2: Operator data lines displaying data defined or chosen by the user. By pressing the [Status] key, up to one extra line can be added.
- c. Status line: Status messages displaying text.





#### 4.1.2 Initial Commissioning

The easiest way of carrying out the initial commissioning is by using the Quick Menu button and follow the quick set-up procedure using Keypad (read table from left to right). The example applies to open loop applications:

4

Press		
<b>Quick Menu</b>	<b>↓</b>	<b>Q2 Quick Set-Up</b>
par. K-01 Language	<b>OK</b>	Set language
par. K-02 Motor Speed Unit	<b>OK</b>	Set motor speed in Hz or RPM
par. P-02 Motor Power [HP] or par. P-07 Motor Power [kW]	<b>OK</b>	Set Motor nameplate power
par. F-05 Motor Rated Voltage	<b>OK</b>	Set Nameplate voltage
par. F-04 Base Frequency	<b>OK</b>	Set Nameplate frequency
par. P-03 Motor Current	<b>OK</b>	Set Nameplate current
par. P-06 Base Speed	<b>OK</b>	Set Nameplate speed in RPM
par. F-01 Frequency Setting 1	<b>OK</b>	Set reference source
par. F-02 Operation Method	<b>OK</b>	Select which reference site to activate
par. F-07 Accel Time 1	<b>OK</b>	Set the accel time with reference to synchronous motor speed, n <sub>s</sub>
par. F-08 Decel Time 1	<b>OK</b>	Set the decel time with reference to synchronous motor speed, n <sub>s</sub>
par. F-10 Electronic Overload	<b>OK</b>	Set motor thermal protection
par. F-15 Motor Speed High Limit [Hz] or par. F-17 Motor Speed High Limit [RPM]	<b>OK</b>	Set motor speed high limit in Hz or RPM
par. F-16 Motor Speed Low Limit [Hz] or par. F-18 Motor Speed Low Limit [RPM]	<b>OK</b>	Set motor speed low limit in Hz or RPM
par. H-08 Reverse Lock	<b>OK</b>	Set allowed rotation direction
par. P-04 Auto Tune	<b>OK</b>	Set desired auto tune function. Enable complete auto tune is recommended



## 4.2 Quick Setup Parameter List

### K-01 Language

Option:	Function:
	Defines the language to be used in the display. The frequency converter is delivered with 4 different languages.
[0] * English	Part of Language packages 1 - 4

### K-02 Motor Speed Unit

Option:	Function:
	This parameter cannot be adjusted while the motor is running. The display showing depends on settings in par. K-02 Motor Speed Unit and par. K-03 Regional Settings. The default setting of par. K-02 Motor Speed Unit and par. K-03 Regional Settings depends on which region of the world the frequency converter is supplied to, but can be re-programmed as required.
	<b>NB!</b> Changing the <i>Motor Speed Unit</i> will reset certain parameters to their initial value. It is recommended to select the motor speed unit first, before modifying other parameters.

[0] RPM Selects display of motor speed variables and parameters (i.e. references, feedbacks and limits) in terms of motor speed (RPM).

[1] \* Hz Selects display of motor speed variables and parameters (i.e. references, feedbacks and limits) in terms of output frequency to the motor (Hz).

### P-02 Motor Power [HP]

Range:	Function:
4.00 hp* [0.09 - 3000.00 hp]	Enter the nominal motor power in HP according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. This parameter is visible in Keypad if par. K-03 Regional Settings is US [1]

### P-07 Motor Power [kW]

Range:	Function:
4.00 kW* [0.09 - 3000.00 kW]	Enter the nominal motor power in kW according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. This parameter cannot be adjusted while the motor is running. This parameter is visible in Keypad if par. K-03 Regional Settings is International [0].

### F-05 Motor Rated Voltage

Range:	Function:
400. V* [10. - 1000. V.]	Enter the nominal motor voltage according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. This parameter cannot be adjusted while the motor is running.

### F-04 Base Frequency

Range:	Function:
50. Hz* [20 - 1000 Hz]	Min - Max motor frequency: 20 - 1000 Hz. Select the motor frequency value from the motor nameplate data. If a value different from 50 Hz or 60 Hz is selected, it is necessary to adapt the load independent settings in par. H-50 Motor Magnetisation at Zero Speed to par. H-53 Model Shift Frequency. For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. Adapt par. F-17 Motor Speed High Limit [RPM] and par. F-53 Maximum Reference to the 87 Hz application.



### P-03 Motor Current

**Range:**

7.20 A\* [0.10 - 10000.00 A]

**Function:**

Enter the nominal motor current value from the motor nameplate data. This data is used for calculating motor torque, motor thermal protection etc.

**NB!**

This parameter cannot be adjusted while the motor is running.

4

### P-06 Base Speed

**Range:**

1420. RPM\* [100 - 60000 RPM]

**Function:**

Enter the nominal motor speed value from the motor nameplate data. This data is used for calculating automatic motor compensations.

**NB!**

This parameter cannot be changed while the motor is running.

### F-01 Frequency Setting 1

**Option:****Function:**

Select the reference input to be used for the first reference signal. par. F-01 *Frequency Setting 1*, par. C-30 *Frequency Command 2* and par. C-34 *Frequency Command 3* define up to three different reference signals. The sum of these reference signals defines the actual reference.

[0] No function

[1] \* Analog Input 53

[2] Analog Input 54

[7] Frequency input 29

[8] Frequency input 33

[11] Local bus reference

[20] Digital Potentiometer

[21] Analog input X30-11 (OPCGPIO - General Purpose I/O Option Module)

[22] Analog input X30-12 (OPCGPIO - General Purpose I/O Option Module)

### F-02 Operation Method

**Option:****Function:**

Select which reference site to activate.

[0] \* Linked to Hand / Auto Use local reference when in Hand mode; or remote reference when in Auto mode.

[1] Remote Use remote reference in both Hand mode and Auto mode.

[2] Local Use local reference in both Hand mode and Auto mode.

**NB!**

When set to Local [2], the frequency converter will start with this setting again following a 'power down'.

### F-07 Accel Time 1

**Range:**

3.00 s\* [0.01 - 3600.00 s]

**Function:**

Enter the accel time, i.e. the acceleration time from 0 RPM to the synchronous motor speed  $n_s$ . Choose a accel time such that the output current does not exceed the current limit in par. F-43 *Current Limit* during ramping. The value 0.00 corresponds to 0.01 sec. in speed mode. See decel time in par. F-08 *Decel Time 1*.



$$\text{Par. F - 07} = \frac{t_{acc} [\text{s}] \times n_s [\text{RPM}]}{\text{ref} [\text{RPM}]}$$

#### F-08 Decel Time 1

**Range:**

3.00 s\* [0.01 - 3600.00 s]

**Function:**

Enter the decel time, i.e. the deceleration time from the synchronous motor speed  $n_s$  to 0 RPM. Choose a decel time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. F-43 Current Limit. The value 0.00 corresponds to 0.01 s in speed mode. See accel time in par. F-07 Accel Time 1.

$$\text{Par. F - 08} = \frac{t_{dec} [\text{s}] \times n_s [\text{RPM}]}{\text{ref} [\text{RPM}]}$$

#### F-10 Electronic Overload

**Option:****Function:**

The frequency converter determines the motor temperature for motor protection in two different ways:

- Via a thermistor sensor connected to one of the analog or digital inputs (par. F-12 Motor Thermistor Input).
- Via calculation of the thermal load, based on the actual load and time. The calculated thermal load is compared with the rated motor current  $I_{M,N}$  and the rated motor frequency  $f_{M,N}$ . The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.

[0] \* No protection

Continuously overloaded motor, when no warning or trip of the frequency converter is required.

[1] Thermistor warning

Activates a warning when the connected thermistor or KTY-sensor in the motor reacts in the event of motor over-temperature.

[2] Thermistor trip

Stops (trips) frequency converter when connected thermistor in motor reacts in the event of motor over-temperature.

The thermistor cut-out value must be > 3 kΩ.

Integrate a thermistor (PTC sensor) in the motor for winding protection.

[3] Electronic Overload Warning 1

[4] Electronic Overload Trip 1

[5] Electronic Overload Warning 2


[6] Electronic Overload Trip 2

[7] Electronic Overload Warning 3

[8] Electronic Overload Trip 3

[9] Electronic Overload Warning 4

[10] Electronic Overload Trip 4





Motor protection can be implemented using a range of techniques: PTC or KTY sensor (see also section *KTY Sensor Connection*) in motor windings; mechanical thermal switch (Klixon type); or Electronic Thermal Overload.

Using a digital input and 24 V as power supply:


Example: The frequency converter trips when the motor temperature is too high

Parameter set-up:

Set par. F-10 *Electronic Overload to Thermistor Trip* [2]

Set par. F-12 *Motor Thermistor Input to Digital Input* [6]

4




Using a digital input and 10 V as power supply:

Example: The frequency converter trips when the motor temperature is too high.

Parameter set-up:

Set par. F-10 *Electronic Overload to Thermistor Trip* [2]

Set par. F-12 *Motor Thermistor Input to Digital Input* [6]






Using an analog input and 10 V as power supply:

Example: The frequency converter trips when the motor temperature is too high.

Parameter set-up:

Set par. F-10 *Electronic Overload to Thermistor Trip [2]*

Set par. F-12 *Motor Thermistor Input to Analog Input 54 [2]*



4

Input	Supply Voltage	Threshold
Digital/analog	Volt	Cut-out Values
Digital	24 V	< 6.6 kΩ - > 10.8 kΩ
Digital	10 V	< 800Ω - > 2.7 kΩ
Analog	10 V	< 3.0 kΩ - > 3.0 kΩ

**NB!**


Check that the chosen supply voltage follows the specification of the used thermistor element.

Select *Electronic Overload Warning 1-4*, to activate a warning on the display when the motor is overloaded.

Select *Electronic Overload Trip 1-4* to trip the frequency converter when the motor is overloaded.

Programme a warning signal via one of the digital outputs. The signal appears in the event of a warning and if the frequency converter trips (thermal warning).

Electronic Overload functions 1-4 will calculate the load when the set-up where they were selected is active. For example Electronic Overload 3 starts calculating when setup 3 is selected. For the North American market: The Electronic Overload functions provide class 20 motor overload protection in accordance with NEC.

**F-15 Motor Speed High Limit (Hz)****Range:**

50/60.0 Hz\* [par. H-12 - par. H-19 Hz]

**Function:**

Enter the maximum limit for motor speed. The Motor Speed High Limit can be set to correspond to the manufacturer's recommended maximum of the motor shaft. The Motor Speed High Limit must exceed the in par. F-16 Frequency Limiter (Low). Only par. F-18 Speed Limiter (Low) or par. F-16 Frequency Limiter (Low) will be displayed depending on other parameters in the Main Menu and depending on default settings dependant on global location.

**NB!**

Max. output frequency cannot exceed 10% of the inverter frequency (par. F-26 Motor Noise (Carrier Freq)).

**F-16 Motor Speed Low Limit [Hz]****Range:**

0 Hz\* [0.0 - par. H-14 Hz]

**Function:**

Enter the minimum limit for motor speed. The Motor Speed Low Limit can be set to correspond to the minimum output frequency of the motor shaft. The Motor Speed Low Limit must not exceed the setting in par. F-15 Motor Speed High Limit [Hz].

4

**F-17 Motor Speed High Limit [RPM]****Range:**

3600. RPM\* [par. H-11 - 60000. RPM]

**Function:**

Enter the maximum limit for motor speed. The Motor Speed High Limit can be set to correspond to the manufacturer's maximum rated motor speed. The Motor Speed High Limit must exceed the setting in par. F-18 Motor Speed Low Limit [RPM].

**NB!**

Max. output frequency cannot exceed 10% of the inverter switching frequency (par. F-26 Motor Noise (Carrier Freq)).

**F-18 Motor Speed Low Limit [RPM]****Range:**

0 RPM\* [0 - par. H-13 RPM]

**Function:**

Enter the minimum limit for motor speed. The Motor Speed Low Limit can be set to correspond to the manufacturer's recommended minimum motor speed. The Motor Speed Low Limit must not exceed the setting in par. F-17 Motor Speed High Limit [RPM].

**H-08 Reverse Lock****Option:****Function:**

Select the motor speed direction(s) required. Use this parameter to prevent unwanted reversing. When par. H-40 Configuration Mode is set to *Process [3]*, par. H-08 Reverse Lock is set to *Clockwise [0]* as default. The setting in par. H-08 Reverse Lock does not limit options for setting par. F-15 Motor Speed High Limit [Hz] or par. F-17 Motor Speed High Limit [RPM].

This parameter cannot be adjusted while the motor is running.

**P-04 Auto Tune****Option:****Function:**

The Auto Tune function optimises dynamic motor performance by automatically optimising the advanced motor parameters (par. P-30 Stator Resistance (*Rs*) to par. P-35 Main Reactance (*Xh*)) at motor standstill.

Activate the Auto Tune function by pressing [Hand] after selecting [1] or [2]. See also the section *Auto Tuning* in the AF-650 GP Design Guide. After a normal sequence, the display will read: "Press [OK] to finish Auto Tune". After pressing the [OK] key the frequency converter is ready for operation.

This parameter cannot be adjusted while the motor is running.

[0] \* Off

[1] Enable complete Auto Tune

[2] Enable reduced Auto Tune

## Note:

- For the best results run Auto Tune on a cold motor.
- Auto Tune cannot be performed while the motor is running.
- Auto Tune cannot be performed on permanent magnet motors.

**NB!**

It is important to set motor par. F-04, F-05, and P-02 to P-08 correctly, since these form part of the Auto Tune algorithm. An Auto Tune should be performed to achieve optimum dynamic motor performance. It may take up to 10 min, depending on the power rating of the motor.

**NB!**

Avoid generating external torque during Auto Tune.

**NB!**

If one of the settings in par. F-04, F-05, or P-02 to P-08 is changed, par. P-30 Stator Resistance ( $R_s$ ) to par. P-01 Motor Poles, the advanced motor parameters, will return to default setting.

**NB!**

Auto Tune will work problem-free on 1 motor size down, typically work on 2 motor sizes down, rarely work on 3 sizes down and never work on 4 sizes down. Please keep in mind that the accuracy of the measured motor data will be poorer when you operate on motors smaller than nominal drive size.



### 4.3 Parameter Lists

4



#### 4.3.1 K-## Keypad Set-up

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>K-0#</b>						
K-01	Language	[0] English	1 set-up	TRUE	-	UInt8
K-02	Motor Speed Unit	[0] RPM	2 set-ups	FALSE	-	UInt8
K-03	Regional Settings	[1] US	2 set-ups	FALSE	-	UInt8
K-04	Operating State at Power-up	[1] Forced stop, refcold	All set-ups	TRUE	-	UInt8
<b>K-1#</b>						
K-10	Active Set-up	[1] Set-up 1	1 set-up	TRUE	-	UInt8
K-11	Edit Set-up	[1] Set-up 1	All set-ups	TRUE	-	UInt8
K-12	This Set-up Linked to	[0] Not linked	All set-ups	FALSE	-	UInt8
K-13	Readout: Linked Set-ups	0 N/A	All set-ups	FALSE	0	UInt16
K-14	Readout: Edit Set-ups / Channel	0 N/A	All set-ups	TRUE	0	Int32
<b>K-2#</b>						
K-20	Display Line 1.1 Small	ExpressionLimit	All set-ups	TRUE	-	UInt16
K-21	Display Line 1.2 Small	ExpressionLimit	All set-ups	TRUE	-	UInt16
K-22	Display Line 1.3 Small	ExpressionLimit	All set-ups	TRUE	-	UInt16
K-23	Display Line 2. Large	ExpressionLimit	All set-ups	TRUE	-	UInt16
K-24	Display Line 3. Large	ExpressionLimit	All set-ups	TRUE	-	UInt16
K-25	Quick Start	ExpressionLimit	1 set-up	TRUE	0	UInt16
<b>K-3#</b>						
K-30	Unit for Custom Readout	[0] None	All set-ups	TRUE	-	UInt8
K-31	Min Value of Custom Readout	0.00	All set-ups	TRUE	-2	Int32
K-32	Max Value of Custom Readout	100.00	All set-ups	TRUE	-2	Int32
<b>K-4#</b>						
K-40	[Hand] Button on Keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
K-41	[Off] Button on Keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
K-42	[Auto] Button on Keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
K-43	[Reset] Button on Keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
<b>K-5#</b>						
K-50	Keypad Copy	[0] No copy	All set-ups	FALSE	-	UInt8
K-51	Set-up Copy	[0] No copy	All set-ups	FALSE	-	UInt8
<b>K-6#</b>						
K-60	Main Menu Password	100 N/A	1 set-up	TRUE	0	Int16
K-61	Access to Main Menu w/o Password	[0] Full access	1 set-up	TRUE	-	UInt8
K-65	Quick Menu Password	200 N/A	1 set-up	TRUE	0	Int16
K-66	Access to Quick Menu w/o Password	[0] Full access	1 set-up	TRUE	-	UInt8
K-67	Bus Password Access	0 N/A	All set-ups	TRUE	0	UInt16



#### 4.3.2 F-## Fundamental Parameters

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>F-0#</b>						
F-01	Frequency Setting 1	null	All set-ups	TRUE	-	Uint8
F-02	Operation Method	[0] Linked to Hand / Auto	All set-ups	TRUE	-	Uint8
F-03	Max Output Frequency 1	132.0 Hz	All set-ups	FALSE	-1	Unit16
F-04	Base Frequency	ExpressionLimit	All set-ups	FALSE	0	Unit16
F-05	Motor Rated Voltage	ExpressionLimit	All set-ups	FALSE	0	Unit16
F-07	Accel Time 1	ExpressionLimit	All set-ups	TRUE	-2	Unit32
F-08	Decel Time 1	ExpressionLimit	All set-ups	TRUE	-2	Unit32
F-09	Torque Boost	100 %	All set-ups	TRUE	0	Int16
<b>F-1#</b>						
F-10	Electronic Overload	[0] No protection	All set-ups	TRUE	-	Uint8
F-11	Motor External Fan	[0] No	All set-ups	TRUE	-	Unit16
F-12	Motor Thermistor Input	[0] None	All set-ups	TRUE	-	Unit8
F-15	Motor Speed High Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Unit16
F-16	Motor Speed Low Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Unit16
F-17	Motor Speed High Limit [RPM]	ExpressionLimit	All set-ups	TRUE	67	Unit16
F-18	Motor Speed Low Limit [RPM]	ExpressionLimit	All set-ups	TRUE	67	Unit16
<b>F-2#</b>						
F-22	Start Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Unit16
F-23	Start Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Unit16
F-24	Holding Time	0.0 s	All set-ups	TRUE	-1	Unit8
F-25	Start Function	[2] Coast/delay time	All set-ups	TRUE	-	Unit8
F-26	Motor Noise Carrier Freq	null	All set-ups	TRUE	-	Unit8
F-27	Motor Tone Random	[0] Off	All set-ups	TRUE	-2	Unit32
F-29	Start Current	0.00 A	All set-ups	TRUE	-2	Unit32
<b>F-3#</b>						
F-37	Adv. Switching Pattern	[1] SFAVM	All set-ups	TRUE	-	Uint8
F-38	Overmodulation	[1] On	All set-ups	FALSE	-	Uint8
<b>F-4#</b>						
F-40	Torque Limiter (Driving)	ExpressionLimit	All set-ups	TRUE	-1	Unit16
F-41	Torque Limiter (Braking)	100.0 %	All set-ups	TRUE	-1	Unit16
F-43	Current Limit	ExpressionLimit	All set-ups	TRUE	-1	Unit32
<b>F-5#</b>						
F-50	Reference Range	null	All set-ups	TRUE	-	Unit8
F-51	Reference/Feedback Unit	null	All set-ups	TRUE	-	Unit8
F-52	Minimum Reference	0 Reference/FeedbackUnit	All set-ups	TRUE	-3	Int32
F-53	Maximum Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
F-54	Reference Function	[0] Sum	All set-ups	TRUE	-	Unit8
<b>F-6#</b>						
F-62	Catch up/slow Down Value	0.00 %	All set-ups	TRUE	-2	Int16
F-64	Preset Relative Reference	0.00 %	All set-ups	TRUE	-2	Int32
F-68	Relative Scaling Reference Resource	[0] No function	All set-ups	TRUE	-	Unit8
<b>F-9#</b>						
F-90	Step Size	0.10 %	All set-ups	TRUE	-2	Unit16
F-91	Accel/Decel Time	1.00 s	All set-ups	TRUE	-2	Unit32
F-92	Power Restore	[0] Off	All set-ups	TRUE	-	Unit8
F-93	Maximum Limit	100 %	All set-ups	TRUE	0	Int16
F-94	Minimum Limit	-100 %	All set-ups	TRUE	0	Int16
F-95	Accel/Decel Ramp Delay	ExpressionLimit	All set-ups	TRUE	-3	TimD



#### 4.3.3 E-## Digital In/Outs

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>E-0#</b>						
E-00	Digital I/O Mode	[0] PNP	All set-ups	FALSE	-	UInt8
E-01	Terminal 18 Digital Input	null	All set-ups	TRUE	-	UInt8
E-02	Terminal 19 Digital Input	null	All set-ups	TRUE	-	UInt8
E-03	Terminal 27 Digital Input	null	All set-ups	TRUE	-	UInt8
E-04	Terminal 29 Digital Input	null	All set-ups	TRUE	-	UInt8
E-05	Terminal 32 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-06	Terminal 33 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-07	Terminal 37 Safe Stop	[1] Safe Stop Alarm	1 set-up	TRUE	-	UInt8
<b>E-1#</b>						
E-10	Accel Time 2	ExpressionLimit	All set-ups	TRUE	-2	UInt32
E-11	Decel Time 2	ExpressionLimit	All set-ups	TRUE	-2	UInt32
E-12	Accel Time 3	ExpressionLimit	All set-ups	TRUE	-2	UInt32
E-13	Decel Time 3	ExpressionLimit	All set-ups	TRUE	-2	UInt32
E-14	Accel Time 4	ExpressionLimit	All set-ups	TRUE	-2	UInt32
E-15	Decel Time 4	ExpressionLimit	All set-ups	TRUE	-2	UInt32
<b>E-2#</b>						
E-20	Terminal 27 Digital Output	null	All set-ups	TRUE	-	UInt8
E-21	Terminal 29 Digital Output	null	All set-ups	TRUE	-	UInt8
E-24	Function Relay	0.01 s	All set-ups	TRUE	-	UInt16
E-26	On Delay, Relay	0.01 s	All set-ups	TRUE	-2	UInt16
E-27	Off Delay, Relay	0.01 s	All set-ups	TRUE	-2	UInt16
<b>E-3#</b>						
E-30	Terminal X46/1 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-31	Terminal X46/3 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-32	Terminal X46/5 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-33	Terminal X46/7 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-34	Terminal X46/9 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-35	Terminal X46/11 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-36	Terminal X46/13 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
<b>E-5#</b>						
E-51	Terminal 27 Mode	[0] Input	All set-ups	TRUE	-	UInt8
E-52	Terminal 29 Mode	[0] Input	All set-ups	TRUE	-	UInt8
E-53	Terminal X30/2 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-54	Terminal X30/3 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-55	Terminal X30/4 Digital Input	[0] No operation	All set-ups	TRUE	-	UInt8
E-56	Term X30/6 Digi Out (OPCGPIO)	null	All set-ups	TRUE	-	UInt8
E-57	Term X30/7 Digi Out (OPCGPIO)	null	All set-ups	TRUE	-	UInt8
<b>E-6#</b>						
E-60	Term. 29 Low Frequency	100 Hz	All set-ups	TRUE	0	UInt32
E-61	Term. 29 High Frequency	100 Hz	All set-ups	TRUE	0	UInt32
E-62	Term. 29 Low Ref./Feedb. Value	0.000 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
E-63	Term. 29 High Ref./Feedb. Value	ExpressionLimit	All set-ups	FALSE	-3	Int32
E-64	Pulse Filter Time Constant #29	100 ms	All set-ups	TRUE	0	UInt16
E-65	Term. 33 Low Frequency	100 Hz	All set-ups	TRUE	0	UInt32
E-66	Term. 33 High Frequency	100 Hz	All set-ups	TRUE	0	UInt32
E-67	Term. 33 Low Ref./Feedb. Value	0.000 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
E-68	Term. 33 High Ref./Feedb. Value	ExpressionLimit	All set-ups	FALSE	-3	Int32
E-69	Pulse Filter Time Constant #33	100 ms	All set-ups	TRUE	-3	UInt16



Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>E7#</b>						
E70	Terminal 27 Pulse Output Variable	null	All set-ups	TRUE	-	UInt8
E72	Pulse Output Max Freq #27	ExpressionLimit	All set-ups	TRUE	0	UInt32
E73	Terminal 29 Pulse Output Variable	null	All set-ups	TRUE	-	UInt8
E75	Pulse Output Max Freq #29	ExpressionLimit	All set-ups	TRUE	0	UInt32
E76	Terminal X30/6 Pulse Output Variable	null	All set-ups	TRUE	-	UInt8
E78	Pulse Output Max Freq #X30/6	ExpressionLimit	All set-ups	TRUE	0	UInt32
<b>E8#</b>						
E80	Term 32/33 Pulses Per Revolution	1024 N/A	All set-ups	FALSE	0	UInt16
E81	Term 32/33 Encoder Direction	[0] Clockwise	All set-ups	FALSE	-	UInt8
<b>E9#</b>						
E90	Digital & Relay Bus Control	0 N/A	All set-ups	TRUE	0	UInt32
E93	Pulse Out #27 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
E94	Pulse Out #27 Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16
E95	Pulse Out #29 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
E96	Pulse Out #29 Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16



#### 4.3.4 C-## Frequency Control Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>C-0#</b>						
C-01	Jump Frequency From [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
C-02	Jump Speed From [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
C-03	Jump Speed To [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
C-04	Jump Frequency To [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
C-05	Multi-step Frequency 1 - 8	0.00 %	All set-ups	TRUE	-2	Int16
<b>C-2#</b>						
C-20	Jog Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
C-21	Jog Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
C-22	Jog Accel/Decel Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
C-23	Quick Stop Decel Time	ExpressionLimit	2 set-ups	TRUE	-2	Uint32
<b>C-3#</b>						
C-30	Frequency Command 2	null	All set-ups	TRUE	-	Uint8
C-34	Frequency Command 3	null	All set-ups	TRUE	-	Uint8



#### 4.3.5 P-## Motor Data

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>P-0#</b>						
P-01	Motor Poles	ExpressionLimit	All set-ups	FALSE	0	Uint8
P-02	Motor Power [HP]	ExpressionLimit	All set-ups	FALSE	-2	Uint32
P-03	Motor Current	ExpressionLimit	All set-ups	FALSE	-2	Uint32
P-04	Auto Tune	[0] Off	All set-ups	FALSE	-	Uint8
P-05	Motor Cont. Rated Torque	ExpressionLimit	All set-ups	FALSE	-1	Uint32
P-06	Base Speed	ExpressionLimit	All set-ups	FALSE	67	Uint16
P-07	Motor Power [kW]	ExpressionLimit	All set-ups	FALSE	1	Uint32
P-09	Slip Compensation	ExpressionLimit	All set-ups	TRUE	0	Int16
<b>P-1#</b>						
P-10	Slip Compensation Time Constant	ExpressionLimit	All set-ups	TRUE	-2	Uint16
<b>P-2#</b>						
P-20	Motor Construction	[0] Asynchron	All set-ups	FALSE	-	Uint8
<b>P-3#</b>						
P-30	Stator Resistance [Rs]	ExpressionLimit	All set-ups	FALSE	-4	Uint32
P-31	Rotor Resistance [Rt]	ExpressionLimit	All set-ups	FALSE	-4	Uint32
P-33	Stator Leakage Reactance [X1]	ExpressionLimit	All set-ups	FALSE	-4	Uint32
P-34	Rotor Leakage Reactance [X2]	ExpressionLimit	All set-ups	FALSE	-4	Uint32
P-35	Main Reactance [Xh]	ExpressionLimit	All set-ups	FALSE	-4	Uint32
P-36	Iron Loss Resistance [Rfe]	ExpressionLimit	All set-ups	FALSE	-3	Uint32
P-37	d-axis Inductance [Ld]	ExpressionLimit	All set-ups	FALSE	-6	Uint32



#### 4.3.6 H-## High Perf Parameters

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>H-0#</b>						
H-03	Restore Factory Settings	[0] Normal operation	All set-ups	TRUE	-	Uint8
H-04	Auto-Reset [Times]	[0] Manual reset	All set-ups	TRUE	-	Uint8
H-05	Auto-Reset (Reset Interval)	10 s	All set-ups	0	0	Uint16
H-07	Accel/Decel Time 1 Type	[0] Linear	All set-ups	TRUE	-	Uint8
H-08	Reverse Lock	null	All set-ups	FALSE	-	Uint8
H-09	Start Mode	[0] Disabled	All set-ups	FALSE	-	Uint8
<b>H-2#</b>						
H-20	Motor Feedback Loss Function	[2] Trip	All set-ups	TRUE	-	Uint8
H-21	Motor Feedback Speed Error	300 RPM	All set-ups	TRUE	67	Uint16
H-22	Motor Feedback Loss Timeout	0.05 s	All set-ups	TRUE	-2	Uint16
<b>H-4#</b>						
H-40	Configuration Mode	null	All set-ups	TRUE	-	Uint8
H-41	Motor Control Principle	null	All set-ups	FALSE	-	Uint8
H-42	Flux Motor Feedback Source	[1] 24V encoder	All set-ups	FALSE	-	Uint8
H-43	Torque Characteristics	[0] Constant torque	All set-ups	TRUE	-	Uint8
H-44	Constant or Variable Torque OL	[0] High torque	All set-ups	FALSE	-	Uint8
H-45	Local Mode Configuration	[2] As mode par H-40	All set-ups	TRUE	-	Uint8
H-46	Back EMF at 1000 RPM	ExpressionLimit	All set-ups	FALSE	0	Uint16
H-47	Motor Angle Offset	0 N/A	All set-ups	FALSE	0	Int16
<b>H-5#</b>						
H-50	Motor Magnetisation at Zero Speed	100 %	All set-ups	TRUE	0	Uint16
H-51	Min Speed Normal Magnetising [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
H-52	Min Speed Normal Magnetising [Hz]	ExpressionLimit	All set-ups	FALSE	-1	Uint16
H-53	Model Shift Frequency	ExpressionLimit	All set-ups	TRUE	-1	Uint16
H-55	U/f Characteristic - U	ExpressionLimit	All set-ups	TRUE	-1	Uint16
H-56	U/f Characteristic - F	ExpressionLimit	All set-ups	TRUE	-1	Uint16
<b>H-6#</b>						
H-61	High Speed Load Compensation	100 %	All set-ups	TRUE	0	Int16
H-64	Resonance Damping	100 %	All set-ups	TRUE	0	Uint16
H-65	Resonance Damping Time Constant	5 ms	All set-ups	TRUE	-3	Uint8
H-66	Min. Current at Low Speed	100 %	All set-ups	TRUE	0	Uint8
<b>H-7#</b>						
H-70	Warning Current Low	0.00 A	All set-ups	TRUE	-2	Uint32
H-71	Warning Current High	Imax/LT [P1637]	All set-ups	TRUE	-2	Uint32
H-72	Warning Speed Low	0 RPM	All set-ups	TRUE	67	Uint16
H-73	Warning Speed High	outputSpeedHigh/limit [P413]	All set-ups	TRUE	67	Uint16
H-74	Warning Reference Low	-999999.999 N/A	All set-ups	TRUE	-3	Int32
H-75	Warning Reference High	999999.999 N/A	All set-ups	TRUE	-3	Int32
H-76	Warning Feedback Low	-999999.999 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
H-77	Warning Feedback High	999999.999 ReferenceFeedbackUnit	All set-ups	TRUE	-	Uint8
H-78	Missing Motor Phase Function	null	All set-ups	TRUE	-	Uint8



Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>H-8#</b>						
H-80	Function at Stop	[0] Coast	TRUE	-	Unit8	
H-81	Min Speed for Function at Stop [RPM]	ExpressionLimit	TRUE	67	Unit16	
H-82	Min Speed for Function at Stop [Hz]	ExpressionLimit	TRUE	-1	Unit16	
H-83	Precise Stop Function	[0] Precise ramp stop	FALSE	-	Unit8	
H-84	Precise Stop Counter Value	100000 N/A	TRUE	0	Unit32	
H-85	Precise Stop Speed Compensation Delay	10 ms	TRUE	-3	Unit8	
H-87	Load Type	[0] Passive load	TRUE	-	Unit8	
H-88	Minimum Inertia	ExpressionLimit	FALSE	-4	Unit32	
H-89	Maximum Inertia	ExpressionLimit	FALSE	-4	Unit32	
<b>H-9#</b>						
H-95	KTY Sensor Type	[0] KTY Sensor 1	TRUE	-	Unit8	
H-96	KTY Thermistor Input	[0] None	TRUE	-	Unit8	
H-97	KTY Threshold level	80 °C	1 set-up	TRUE	100	Int16



#### 4.3.7 AN-## Analog In / Out

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>AN-0#</b>						
AN-00	Live Zero Timeout Time	10 s	All set-ups	TRUE	0	UInt8
AN-01	Live Zero Timeout Function	[0] Off	All set-ups	TRUE	-	UInt8
<b>AN-1#</b>						
AN-10	Terminal 53 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
AN-11	Terminal 53 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
AN-12	Terminal 53 Low Current	0.14 mA	All set-ups	TRUE	-5	Int16
AN-13	Terminal 53 High Current	20.00 mA	All set-ups	TRUE	-5	Int16
AN-14	Terminal 53 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
AN-15	Terminal 53 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
AN-16	Terminal 53 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
<b>AN-2#</b>						
AN-20	Terminal 54 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
AN-21	Terminal 54 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
AN-22	Terminal 54 Low Current	0.14 mA	All set-ups	TRUE	-5	Int16
AN-23	Terminal 54 High Current	20.00 mA	All set-ups	TRUE	-5	Int16
AN-24	Terminal 54 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
AN-25	Terminal 54 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
AN-26	Terminal 54 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
<b>AN-3#</b>						
AN-30	Terminal X30/11 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
AN-31	Terminal X30/11 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
AN-34	Term. X30/11 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
AN-35	Term. X30/11 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
AN-36	Term. X30/11 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
<b>AN-4#</b>						
AN-40	Terminal X30/12 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
AN-41	Terminal X30/12 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
AN-44	Term. X30/12 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
AN-45	Term. X30/12 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
AN-46	Term. X30/12 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
<b>AN-5#</b>						
AN-50	Terminal 42 Output	null	All set-ups	TRUE	-	UInt8
AN-51	Terminal 42 Output Min Scale	0.00 %	All set-ups	TRUE	-2	Int16
AN-52	Terminal 42 Output Max Scale	100.00 %	All set-ups	TRUE	-2	Int16
AN-53	Terminal 42 Output Bus Control	0.00 %	All set-ups	TRUE	-2	N2
AN-54	Terminal 42 Output Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16
<b>AN-6#</b>						
AN-60	Terminal X30/8 Output	null	All set-ups	TRUE	-	UInt8
AN-61	Terminal X30/8 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
AN-62	Terminal X30/8 Max. Scale	100.00 %	All set-ups	TRUE	-2	Int16
<b>AN-7#</b>						
AN-70	Terminal X45/1 Output	null	All set-ups	TRUE	-	UInt8
AN-71	Terminal X45/1 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
AN-72	Terminal X45/1 Max. Scale	100.00 %	All set-ups	TRUE	-2	Int16
AN-73	Terminal X45/1 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
AN-74	Terminal X45/1 Output Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16
<b>AN-8#</b>						
AN-80	Terminal X45/3 Output	null	All set-ups	TRUE	-	UInt8
AN-81	Terminal X45/3 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
AN-82	Terminal X45/3 Max. Scale	100.00 %	All set-ups	TRUE	-2	Int16
AN-83	Terminal X45/3 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
AN-84	Terminal X45/3 Output Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16



#### 4.3.8 SP-## Special Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>SP-1#</b>						
SP-10	Line failure	[0] No function	All set-ups	FALSE	-	Uint8
SP-11	Line Voltage at Input Fault	ExpressionLimit	All set-ups	TRUE	0	Uint16
SP-12	Function at Line imbalance	[0] Trip	All set-ups	TRUE	-	Uint8
<b>SP-2#</b>						
SP-23	Typecode Setting	null	2 set-ups	FALSE	-	Uint8
SP-24	Trip Delay at Current Limit	60 s	All set-ups	TRUE	0	Uint8
SP-25	Trip Delay at Torque Limit	60 s	All set-ups	TRUE	0	Uint8
SP-26	Trip Delay at Drive Fault	ExpressionLimit	All set-ups	TRUE	0	Uint8
SP-28	Production Settings	[0] No action	All set-ups	TRUE	-	Uint8
SP-29	Service Code	0 N/A	All set-ups	TRUE	0	Int32
<b>SP-3#</b>						
SP-30	Current Lim Cont. Proportional Gain	100 %	All set-ups	FALSE	0	Uint16
SP-31	Current Lim Contr. Integration Time	0.020 s	All set-ups	FALSE	-3	Uint16
<b>SP-4#</b>						
SP-40	VT Level	66 %	All set-ups	FALSE	0	Uint8
SP-41	Energy Savings Min. Magnetisation	ExpressionLimit	All set-ups	TRUE	0	Uint8
SP-42	Energy Savings Min. Frequency	10 Hz	All set-ups	TRUE	0	Uint8
SP-43	Motor Cosphi	ExpressionLimit	All set-ups	TRUE	-2	Uint16
<b>SP-5#</b>						
SP-50	RF Filter	[1] On	1 set-up	FALSE	-	Uint8
SP-52	Fan Operation	[0] Auto	All set-ups	TRUE	-	Uint8
SP-53	Fan Monitor	[1] Warning	All set-ups	TRUE	-	Uint8
SP-55	Output Filter	[0] No Filter	1 set-up	FALSE	-	Uint8
SP-56	Capacitance Output Filter	2.0 uF	1 set-up	FALSE	-7	Uint16
SP-57	Inductance Output Filter	7.000 mH	1 set-up	FALSE	-6	Uint16
SP-59	Actual Number of Inverter Units	ExpressionLimit	1 set-up	FALSE	0	Uint8
<b>SP-6#</b>						
SP-63	Option Supplied by External 24VDC	[1] Yes	2 set-ups	FALSE	-	Uint8
<b>SP-7#</b>						
SP-71	Accel Time 1 S-ramp Ratio at Accel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-72	Accel Time 1 S-ramp Ratio at Accel. End	50 %	All set-ups	TRUE	0	Uint8
SP-73	Decel Time 1 S-ramp Ratio at Decel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-74	Decel Time 1 S-ramp Ratio at Decel. End	50 %	All set-ups	TRUE	-	Uint8
SP-76	Accel/Decel Time 2 Type	[0] Linear	All set-ups	TRUE	0	Uint8
SP-79	Accel Time 2 S-ramp Ratio at Accel. Start	50 %	All set-ups	TRUE	0	Uint8
<b>SP-8#</b>						
SP-80	Accel Time 2 S-ramp Ratio at Accel. End	50 %	All set-ups	TRUE	0	Uint8
SP-81	Decel Time 2 S-ramp Ratio at Decel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-82	Decel Time 2 S-ramp Ratio at Decel. End	50 %	All set-ups	TRUE	0	Uint8
SP-84	Accel/Decel Ramp 3 Type	[0] Linear	All set-ups	TRUE	-	Uint8
SP-87	Accel Time 3 S-ramp Ratio at Accel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-88	Accel Time 3 S-ramp Ratio at Accel. End	50 %	All set-ups	TRUE	0	Uint8
SP-89	Decel Time 3 S-ramp Ratio at Decel. Start	50 %	All set-ups	TRUE	0	Uint8
<b>SP-9#</b>						
SP-90	Decel Time 3 S-ramp Ratio at Decel. End	50 %	All set-ups	TRUE	0	Uint8
SP-92	Accel/Decel Ramp 4 Type	[0] Linear	All set-ups	TRUE	-	Uint8
SP-95	Accel Time 4 S-ramp Ratio at Accel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-96	Accel Time 4 S-ramp Ratio at Accel. End	50 %	All set-ups	TRUE	0	Uint8
SP-97	Decel Time 4 S-ramp Ratio at Decel. Start	50 %	All set-ups	TRUE	0	Uint8
SP-98	Decel Time 4 S-ramp Ratio at Decel. End	50 %	All set-ups	TRUE	0	Uint8



#### 4.3.9 O-## Options/Comms

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>O-0#</b>						
O-01	Control Site	[0] Digital and ctrl.word null	All set-ups	TRUE	-	UInt8
O-02	Control Word Source	1.0 s	All set-ups	TRUE	-	UInt8
O-03	Control Word Timeout Time	[0] Off	1 set-up	TRUE	-1	UInt32
O-04	Control Word Timeout Function		1 set-up	TRUE	-	UInt8
O-05	End-of-Timeout Function	[1] Resume set-up	All set-ups	TRUE	-	UInt8
O-06	Reset Control Word Timeout	[0] Do not reset	All set-ups	TRUE	-	UInt8
O-07	Diagnosis Trigger	[0] Disable	2 set-ups	TRUE	-	UInt8
<b>O-1#</b>						
O-10	Control Word Profile	[0] Drive Profile	All set-ups	TRUE	-	UInt8
O-13	Configurable Status Word STW	[1] Profile Default	All set-ups	TRUE	-	UInt8
O-14	Configurable Control Word CTW	[1] Profile default	All set-ups	TRUE	-	UInt8
<b>O-3#</b>						
O-30	Protocol	[0] Drive	1 set-up	TRUE	-	UInt8
O-31	Address	1 N/A	1 set-up	TRUE	0	UInt8
O-32	Drive Port Baud Rate	null	1 set-up	TRUE	-	UInt8
O-33	Drive port parity		1 set-up	TRUE	-	UInt8
O-35	Minimum Response Delay	[0] Even Parity, 1 Stop Bit	All set-ups	TRUE	-	UInt16
O-36	Max Response Delay	10 ms	1 set-up	TRUE	-3	UInt16
O-37	Max Inter-Char Delay	ExpressionLimit	1 set-up	TRUE	-5	UInt16
<b>O-4#</b>						
O-40	Telegram Selection	[1] Standard telegram 1	2 set-ups	TRUE	-	UInt8
<b>O-5#</b>						
O-50	Coasting Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-51	Quick Stop Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-52	DC Brake Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-53	Start Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-54	Reversing Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-55	Set-up Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
O-56	Preset Reference Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
<b>O-8#</b>						
O-80	Bus Message Count	0 N/A	All set-ups	TRUE	0	UInt32
O-81	Bus Error Count	0 N/A	All set-ups	TRUE	0	UInt32
O-82	Slove Messages Rvrd	0 N/A	All set-ups	TRUE	0	UInt32
O-83	Slove Error Count	0 N/A	All set-ups	TRUE	0	UInt32
<b>O-9#</b>						
O-90	Bus Jog 1 Speed	100 RPM	All set-ups	TRUE	67	UInt16
O-91	Bus Jog 2 Speed	200 RPM	All set-ups	TRUE	67	UInt16



#### 4.3.10 DN-## DeviceNet

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>DN-0#</b>						
DN-00	DeviceNet Protocol	null	2 set-ups	FALSE	-	UInt8
DN-01	Baud Rate Select	null	2 set-ups	TRUE	-	UInt8
DN-02	MAC ID	ExpressionLimit	2 set-ups	TRUE	0	UInt8
DN-05	Readout Transmit Error Counter	0 N/A	All set-ups	TRUE	0	UInt8
DN-06	Readout Receive Error Counter	0 N/A	All set-ups	TRUE	0	UInt8
DN-07	Readout Bus Off Counter	0 N/A	All set-ups	TRUE	0	UInt8
<b>DN-1#</b>						
DN-10	Process Data Type Selection	null	All set-ups	TRUE	-	UInt8
DN-11	Process Data Config Write	ExpressionLimit	All set-ups	TRUE	-	UInt16
DN-12	Process Data Config Read	ExpressionLimit	All set-ups	TRUE	-	UInt16
DN-13	Warning Parameter	0 N/A	All set-ups	TRUE	0	UInt16
DN-14	Net Reference	[0] Off	2 set-ups	TRUE	-	UInt8
DN-15	Net Control	[0] Off	2 set-ups	TRUE	-	UInt8
DN-18	internal_process_data_config_write	ExpressionLimit	All set-ups	TRUE	0	UInt16
DN-19	internal_process_data_config_read	ExpressionLimit	All set-ups	TRUE	0	UInt16
<b>DN-2#</b>						
DN-20	COS Filter 1	0 N/A	All set-ups	FALSE	0	UInt16
DN-21	COS Filter 2	0 N/A	All set-ups	FALSE	0	UInt16
DN-22	COS Filter 3	0 N/A	All set-ups	FALSE	0	UInt16
DN-23	COS Filter 4	0 N/A	All set-ups	FALSE	0	UInt16
<b>DN-3#</b>						
DN-30	Array Index	0 N/A	2 set-ups	TRUE	0	UInt8
DN-31	Store Data Values	[0] Off	All set-ups	TRUE	-	UInt8
DN-32	Devicenet Revision	ExpressionLimit	All set-ups	TRUE	0	UInt16
DN-33	Store Always	[0] Off	1 set-up	TRUE	-	UInt8
DN-34	DeviceNet Product Code	ExpressionLimit	1 set-up	TRUE	0	UInt16
DN-39	Devicenet F Parameters	0 N/A	All set-ups	TRUE	0	UInt32
<b>DN-5#</b>						



#### 4.3.11 PB-## Profibus

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>PB-0#</b>						
PB-00	Setpoint	0 N/A	All set-ups	TRUE	0	Uint16
PB-07	Actual Value	0 N/A	All set-ups	FALSE	0	Uint16
<b>PB-1#</b>						
PB-15	PCD Write Configuration					
PB-16	PCD Read Configuration					
PB-18	Node Address					
<b>PB-2#</b>						
PB-22	Telegram Selection	[108] PPO 8	1 set-up	TRUE	-	Uint8
PB-23	Parameters for Signals	0	All set-ups	TRUE	-	Uint16
PB-27	Parameter Edit		2 set-ups	FALSE	-	Uint16
PB-28	Process Control		1 set-up	TRUE	0	Uint8
<b>PB-3#</b>						
PB-31	Safe Address	0 N/A	1 set-up	TRUE	0	Uint16
<b>PB-4#</b>						
PB-44	Fault Message Counter	0 N/A	All set-ups	TRUE	0	Uint16
PB-45	Fault Code	0 N/A	All set-ups	TRUE	0	Uint16
PB-47	Fault Number	0 N/A	All set-ups	TRUE	0	Uint16
<b>PB-5#</b>						
PB-52	Fault Situation Counter	0 N/A	All set-ups	TRUE	0	Uint16
PB-53	Profibus Warning Word	0 N/A	All set-ups	TRUE	0	V2
<b>PB-6#</b>						
PB-63	Actual Baud Rate	[255] No baudrate found	All set-ups	TRUE	-	Uint8
PB-64	Device Identification	0 N/A	All set-ups	TRUE	0	Uint16
PB-65	Profile Number	0 N/A	All set-ups	TRUE	0	OcStr[2]
PB-67	Control Word 1	0 N/A	All set-ups	TRUE	0	V2
PB-68	Status Word 1	0 N/A	All set-ups	TRUE	0	V2
<b>PB-7#</b>						
PB-71	Profibus Save Data Values	[0] Off	All set-ups	TRUE	-	Uint8
PB-72	ProfibusDriveReset	[0] No action	1 set-up	FALSE	-	Uint8
<b>PB-8#</b>						
PB-80	Defined Parameters [1]	0 N/A	All set-ups	FALSE	0	Uint16
PB-81	Defined Parameters [2]	0 N/A	All set-ups	FALSE	0	Uint16
PB-82	Defined Parameters [3]	0 N/A	All set-ups	FALSE	0	Uint16
PB-83	Defined Parameters [4]	0 N/A	All set-ups	FALSE	0	Uint16
PB-84	Defined Parameters [5]	0 N/A	All set-ups	FALSE	0	Uint16
<b>PB-9#</b>						
PB-90	Changed Parameters [1]	0 N/A	All set-ups	FALSE	0	Uint16
PB-91	Changed Parameters [2]	0 N/A	All set-ups	FALSE	0	Uint16
PB-92	Changed Parameters [3]	0 N/A	All set-ups	FALSE	0	Uint16
PB-93	Changed parameters [4]	0 N/A	All set-ups	FALSE	0	Uint16
PB-94	Changed parameters [5]	0 N/A	All set-ups	FALSE	0	Uint16
PB-99	Profibus Revision Counter	0 N/A	All set-ups	TRUE	0	Uint16



#### 4.3.12 ID-## Drive Information

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>ID-0#</b>						
D-00	Operating Hours	0 h	All set-ups	FALSE	74	Unit32
D-01	Running Hours	0 h	All set-ups	FALSE	74	Unit32
D-02	kWh Counter	0 kWh	All set-ups	FALSE	75	Unit32
D-03	PowerUps	0 N/A	All set-ups	FALSE	0	Unit32
D-04	Over Temp's	0 N/A	All set-ups	FALSE	0	Unit16
D-05	Over Volt's	0 N/A	All set-ups	FALSE	0	Unit16
D-06	Reset kWh Counter	[0] Do not reset [0] Do not reset	All set-ups	TRUE	-	Unit8
D-07	Reset Running Hours Counter		All set-ups	TRUE	-	Unit8
<b>ID-1#</b>						
D-10	Trending Source	0	2 set-ups	TRUE	-	Unit16
D-11	Trending Interval	ExpressionLimit [0] False	2 set-ups	TRUE	-3	TimD
D-12	Trigger Event	[0] Trend always	1 set-up	TRUE	-	Unit8
D-13	Trending Mode	50 N/A	2 set-ups	TRUE	0	Unit8
<b>ID-2#</b>						
D-20	Historic Log: Event	0 N/A	All set-ups	FALSE	0	Unit8
D-21	Historic Log: Value	0 N/A	All set-ups	FALSE	0	Unit32
D-22	Historic Log: Time	0 ms	All set-ups	FALSE	-3	Unit32
<b>ID-3#</b>						
D-30	Fault Log: Error Code	0 N/A	All set-ups	FALSE	0	Unit8
D-31	Fault Log: Value	0 N/A	All set-ups	FALSE	0	Int16
D-32	Fault Log: Time	0 s	All set-ups	FALSE	0	Unit32
<b>ID-4#</b>						
D-40	Drive Type	0 N/A	All set-ups	FALSE	0	VsStr[6]
D-41	Power Section	0 N/A	All set-ups	FALSE	0	VsStr[20]
D-42	Voltage	0 N/A	All set-ups	FALSE	0	VsStr[20]
D-43	Software Version	0 N/A	All set-ups	FALSE	0	VsStr[5]
D-44	OrderedTypecode String	0 N/A	All set-ups	FALSE	0	VsStr[40]
D-45	ActualTypecode String	0 N/A	All set-ups	FALSE	0	VsStr[40]
D-46	GE Product No.	0 N/A	All set-ups	FALSE	0	VsStr[8]
D-47	Power Card Ordering No	0 N/A	All set-ups	FALSE	0	VsStr[8]
D-48	Keypad ID Number	0 N/A	All set-ups	FALSE	0	VsStr[20]
D-49	SW ID Control Card	0 N/A	All set-ups	FALSE	0	VsStr[20]
<b>ID-5#</b>						
D-50	SW ID Power Card	0 N/A	All set-ups	FALSE	0	VsStr[20]
D-51	Drive Serial Number	0 N/A	All set-ups	FALSE	0	VsStr[10]
D-53	Power Card Serial Number	0 N/A	All set-ups	FALSE	0	VsStr[19]
<b>ID-6#</b>						
D-60	Option Mounted	0 N/A	All set-ups	FALSE	0	VsStr[30]
D-61	Option SW Version	0 N/A	All set-ups	FALSE	0	VsStr[20]
D-62	Option Ordering No	0 N/A	All set-ups	FALSE	0	VsStr[8]
D-63	Option Serial No	0 N/A	All set-ups	FALSE	0	VsStr[18]



Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>ID-7#</b>						
D-70	Option in Slot A	0 N/A	All set-ups	FALSE	0	Vistr[30]
D-71	Slot A Option SW Version	0 N/A	All set-ups	FALSE	0	Vistr[20]
D-72	Option in Slot B	0 N/A	All set-ups	FALSE	0	Vistr[30]
D-73	Slot B Option SW Version	0 N/A	All set-ups	FALSE	0	Vistr[20]
D-74	Option in Slot C1	0 N/A	All set-ups	FALSE	0	Vistr[30]
D-75	Slot CO Option SW Version	0 N/A	All set-ups	FALSE	0	Vistr[20]
D-76	Option in Slot C2	0 N/A	All set-ups	FALSE	0	Vistr[30]
D-77	Slot C1 Option SW Version	0 N/A	All set-ups	FALSE	0	Vistr[20]
<b>ID-9#</b>						
D-92	Defined Parameters	0 N/A	All set-ups	FALSE	0	Unt16
D-93	Modified Parameters	0 N/A	All set-ups	FALSE	0	Unt16
D-98	Drive Identification	0 N/A	All set-ups	FALSE	0	Vistr[40]
D-99	Parameter Metadata	0 N/A	All set-ups	FALSE	0	Unt16



#### 4.3.13 DR-## Data Readouts

Par. No.	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>DR-0#</b>						
DR-00	Control Word	0 N/A	All set-ups	FALSE	0	V2
DR-01	Reference [Unit]	0.000 ReferenceFeedbackUnit	All set-ups	FALSE	-3	Int32
DR-02	Reference %	0.0 %	All set-ups	FALSE	-1	Int16
DR-03	Status Word	0 N/A	All set-ups	FALSE	0	V2
DR-05	Main Actual Value [%]	0.00 %	All set-ups	FALSE	-2	N2
DR-09	Custom Readout	0.00 CustomReadoutUnit	All set-ups	FALSE	-2	Int32
<b>DR-1#</b>						
DR-10	Power [kW]	0.00 kW	All set-ups	FALSE	1	Int32
DR-11	Power [hp]	0.00 hp	All set-ups	FALSE	-2	Int32
DR-12	Motor Rated Voltage	0.0 V	All set-ups	FALSE	-1	Uint16
DR-13	Frequency	0.0 Hz	All set-ups	FALSE	-1	Uint16
DR-14	Motor Current	0.0 A	All set-ups	FALSE	-2	Int32
DR-15	Frequency [%]	0.00 %	All set-ups	FALSE	-2	N2
DR-16	Torque [Nm]	0.0 Nm	All set-ups	FALSE	-1	Int16
DR-17	Speed [RPM]	0 RPM	All set-ups	FALSE	67	Int32
DR-18	Motor Thermal	0 %	All set-ups	FALSE	0	Uint8
DR-19	KTY sensor temperature	0 °C	All set-ups	FALSE	100	Int16
<b>DR-2#</b>						
DR-20	Motor Angle	0 N/A	All set-ups	TRUE	0	Uint16
DR-22	Torque [%]	0 %	All set-ups	FALSE	0	Uint16
DR-25	Torque [Nm] High	0.0 Nm	All set-ups	FALSE	-1	Int32
<b>DR-3#</b>						
DR-30	DC Link Voltage	0 V	All set-ups	FALSE	0	Uint16
DR-32	Brake Energy /s	0.000 kW	All set-ups	FALSE	0	Uint32
DR-33	Brake Energy /2 min	0.000 kW	All set-ups	FALSE	0	Uint32
DR-34	Heatsink Temp.	0 °C	All set-ups	FALSE	100	Uint8
DR-35	Drive Thermal	0 %	All set-ups	FALSE	0	Uint8
DR-36	Drive Nominal Current	ExpressionLimit	All set-ups	FALSE	-2	Uint32
DR-37	Drive Max. Current	ExpressionLimit	All set-ups	FALSE	-2	Uint32
DR-38	Logic Controller State	0 N/A	All set-ups	FALSE	0	Uint8
DR-39	Control Card Temp.	0 °C	All set-ups	FALSE	100	Uint8
<b>DR-4#</b>						
DR-40	Trending Buffer Full	[0] No	All set-ups	TRUE	-	Uint8
<b>DR-5#</b>						
DR-50	External Reference	0.0 N/A	All set-ups	FALSE	-1	Int16
DR-51	Pulse Reference	0.0 N/A	All set-ups	FALSE	-1	Int16
DR-52	Feedback [Unit]	0.000 ReferenceFeedbackUnit	All set-ups	FALSE	-3	Int32
DR-53	Digi Pot Reference	0.00 N/A	All set-ups	FALSE	-2	Int16
<b>DR-6#</b>						
DR-60	Digital Input	0 N/A	All set-ups	FALSE	0	Uint16
DR-61	Terminal 53 Switch Setting	[0] Current	All set-ups	FALSE	-	Uint8
DR-62	Analog Input 53	0.000 N/A	All set-ups	FALSE	-3	Int32
DR-63	Terminal 54 Switch Setting	[0] Current	All set-ups	FALSE	-	Uint8
DR-64	Analog Input 54	0.000 N/A	All set-ups	FALSE	-3	Int32
DR-65	Analog Output 42 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
DR-66	Digital Output [bin]	0 N/A	All set-ups	FALSE	0	Int16
DR-67	Freq. Input #29 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
DR-68	Freq. Input #33 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
DR-69	Pulse Output #27 [Hz]	0 N/A	All set-ups	FALSE	0	Int32



Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>DR-7#</b>						
DR-70	Pulse Output #29 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
DR-71	Relay Output [bin]	0 N/A	All set-ups	FALSE	0	Int16
DR-72	Counter A	0 N/A	All set-ups	TRUE	0	Int32
DR-73	Counter B	0 N/A	All set-ups	TRUE	0	Int32
DR-74	Prec. Stop Counter	0 N/A	All set-ups	TRUE	0	Unit32
DR-75	Analog In X30/11	0.000 N/A	All set-ups	FALSE	-3	Int32
DR-76	Analog In X30/12	0.000 N/A	All set-ups	FALSE	-3	Int32
DR-77	Analog Out X30/8 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
DR-78	Analog Out X45/1 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
DR-79	Analog Out X45/3 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
<b>DR-8#</b>						
DR-80	Fieldbus CTW 1	0 N/A	All set-ups	FALSE	0	V2
DR-82	Fieldbus REF 1	0 N/A	All set-ups	FALSE	0	N2
DR-84	Comm. Option SW	0 N/A	All set-ups	FALSE	0	V2
DR-85	Drive Port CTW 1	0 N/A	All set-ups	FALSE	0	V2
DR-86	Drive Port REF 1	0 N/A	All set-ups	FALSE	0	N2
<b>DR-9#</b>						
DR-90	Alarm Word	0 N/A	All set-ups	FALSE	0	Unit32
DR-91	Alarm Word 2	0 N/A	All set-ups	FALSE	0	Unit32
DR-92	Warning Word	0 N/A	All set-ups	FALSE	0	Unit32
DR-93	Warning Word 2	0 N/A	All set-ups	FALSE	0	Unit32
DR-94	Ext. Status Word	0 N/A	All set-ups	FALSE	0	Unit32



#### 4.3.14 LC-## Logic Controller

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>LC-0#</b>						
LC-00	Logic Controller Mode	null	2 set-ups	TRUE	-	UInt8
LC-01	Start Event	null	2 set-ups	TRUE	-	UInt8
LC-02	Stop Event	null	2 set-ups	TRUE	-	UInt8
LC-03	Reset Logic Controller	[0] Do not reset Logic Controller	All set-ups	TRUE	-	UInt8
<b>LC-1#</b>						
LC-10	Comparator Operand	null	2 set-ups	TRUE	-	UInt8
LC-11	Comparator Operator	null	2 set-ups	TRUE	-	UInt8
LC-12	Comparator Value	ExpressionLimit	2 set-ups	TRUE	-3	Int32
<b>LC-2#</b>						
LC-20	Logic Controller Timer	ExpressionLimit	1 set-up	TRUE	-3	TimD
<b>LC-4#</b>						
LC-40	Logic Rule Boolean 1	null	2 set-ups	TRUE	-	UInt8
LC-41	Logic Rule Operator 1	null	2 set-ups	TRUE	-	UInt8
LC-42	Logic Rule Boolean 2	null	2 set-ups	TRUE	-	UInt8
LC-43	Logic Rule Operator 2	null	2 set-ups	TRUE	-	UInt8
LC-44	Logic Rule Boolean 3	null	2 set-ups	TRUE	-	UInt8
<b>LC-5#</b>						
LC-51	Logic Controller Event	null	2 set-ups	TRUE	-	UInt8
LC-52	Logic Controller Action	null	2 set-ups	TRUE	-	UInt8



#### 4.3.15 B-## Braking Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>B-0#</b>						
B-00	DC Hold Current	50 %	All set-ups	TRUE	0	Uint8
B-01	DC Brake Current	50 %	All set-ups	TRUE	0	Uint16
B-02	DC Braking Time	10.0 s	All set-ups	TRUE	-1	Uint16
B-03	DC Brake Cut In Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
B-04	DC Brake Cut In Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
<b>B-1#</b>						
B-10	Brake Function	null	All set-ups	TRUE	-	Uint8
B-11	Brake Resistor (ohm)	ExpressionLimit	All set-ups	TRUE	-2	Uint32
B-12	Brake Power Limit (kW)	ExpressionLimit	All set-ups	TRUE	0	Uint32
B-13	Braking Thermal Overload	[0] Off	All set-ups	TRUE	-	Uint8
B-15	Brake Check	[0] Off	All set-ups	TRUE	-	Uint8
B-16	AC brake Max. Current	100.0 %	All set-ups	TRUE	-1	Uint32
B-17	Over-voltage Control	[0] Disabled	All set-ups	TRUE	-	Uint8
<b>B-2#</b>						
B-20	Release Brake Current	ImaxVLT(p1637)	All set-ups	TRUE	-2	Uint32
B-21	Activate Brake Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
B-22	Activate Brake Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
B-23	Activate Brake Delay	0.0 s	All set-ups	TRUE	-1	Uint8
B-24	Stop Delay	0.0 s	All set-ups	TRUE	-1	Uint8
B-25	Brake Release Time	0.20 s	All set-ups	TRUE	-2	Uint16
B-26	Torque Ref	0.00 %	All set-ups	TRUE	-2	Int16
B-27	Torque Ramp Time	0.2 s	All set-ups	TRUE	-1	Uint8
B-28	Gain Boost Factor	1.00 N/A	All set-ups	TRUE	-2	Uint16



#### 4.3.16 PI-## PID Controls

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>PI-0#</b>						
PI-00	Speed PID Feedback Source	null	All set-ups	FALSE	-	UInt8
PI-02	Speed PID Proportional Gain	ExpressionLimit	All set-ups	TRUE	-4	UInt32
PI-03	Speed PID Integral Time	ExpressionLimit	All set-ups	TRUE	-4	UInt32
PI-04	Speed PID Differentiation Time	5.0 N/A	All set-ups	TRUE	-1	UInt16
PI-05	Speed PID Diff. Gain Limit	1000 ms	All set-ups	TRUE	-4	UInt16
PI-06	Speed PID Lowpass Filter Time	1.0000 N/A	All set-ups	FALSE	-4	UInt32
PI-07	Speed PID Feedback Gear Ratio	0 %	All set-ups	FALSE	0	UInt16
PI-08	Speed PID FeedForward Factor					
<b>PI-1#</b>						
PI-12	Torque PI Proportional Gain	100 %	All set-ups	TRUE	0	UInt16
PI-13	Torque PI Integration Time	0.020 s	All set-ups	TRUE	-3	UInt16
<b>PI-2#</b>						
PI-20	Process CL Feedback 1 Resource	[0] No function	All set-ups	TRUE	-	UInt8
PI-22	Process CL Feedback 2 Resource	[0] No function	All set-ups	TRUE	-	UInt8
<b>PI-3#</b>						
PI-30	Process PID Normal/ Inverse Control	[0] Normal	All set-ups	TRUE	-	UInt8
PI-31	Process PID Anti Windup	[1] On	All set-ups	TRUE	-	UInt8
PI-32	Process PID Start Speed	0 RPM	All set-ups	TRUE	67	UInt16
PI-33	Process PID Proportional Gain	0.01 N/A	All set-ups	TRUE	-2	UInt16
PI-34	Process PID Integral Time	10000.00 s	All set-ups	TRUE	-2	UInt32
PI-35	Process PID Differentiation Time	0.00 s	All set-ups	TRUE	-2	UInt16
PI-36	Process PID Diff. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	UInt16
PI-38	Process PID FeedForward Factor	0 %	All set-ups	TRUE	0	UInt16
PI-39	On Reference Bandwidth	5 %	All set-ups	TRUE	0	UInt8



#### 4.3.17 EC-## Feedback Option

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-tion	Conver-sion index	Type
<b>EC-1#</b>						
EC-10	Signal Type	[1] RS422 [5V TTL]	All set-ups	FALSE	-	UInt8
EC-11	Resolution (PPR)	1024 N/A	All set-ups	FALSE	0	UInt16
<b>EC-2#</b>						
EC-20	Protocol Selection	[0] None	All set-ups	FALSE	-	UInt8
EC-21	Resolution (Positions/Rev)	ExpressionLimit 13 N/A	All set-ups	FALSE	0	UInt32
EC-24	SS Data Length	ExpressionLimit	All set-ups	FALSE	0	UInt8
EC-25	Clock Rate	[0] Gray code	All set-ups	FALSE	3	UInt16
EC-26	SS Data Format	[4] 9600	All set-ups	FALSE	-	UInt8
EC-34	HIPERFACE Baudrate		All set-ups	FALSE	-	UInt8
<b>EC-6#</b>						
EC-60	Feedback Direction	[0] Clockwise	All set-ups	FALSE	-	UInt8
EC-61	Feedback Signal Monitoring	[1] Warning	All set-ups	TRUE	-	UInt8



#### 4.3.18 RS-## Resolver Interface

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
<b>RS-5#</b>						
RS-50	Poles	2 N/A	1 set-up	FALSE	0	Uint8
RS-51	Input Voltage	7.0V	1 set-up	FALSE	-1	Uint8
RS-52	Input Frequency	10.0 kHz	1 set-up	FALSE	2	Uint8
RS-53	Transformation Ratio	0.5 N/A	1 set-up	FALSE	-1	Uint8
RS-59	Resolver Interface	[0] Disabled	All set-ups	FALSE	-	Uint8



## 5 General Specifications


### 5.1 Electrical Data - 200-240 V

#### Mains Supply 3 x 200 - 240 VAC

AF-650 GP/AF-650 GP


Typical Shaft Output [kW]	0.25	0.37	0.55	0.75	1.1	1.5	2.2	3	3.7
Typical Shaft Output [HP] at 208 V	0.3	0.5	0.7	1.0	1.5	2.0	2.9	4.0	4.9
Unit Size IP 20/IP 21	12	12	12	12	12	12	12	13	13
Unit Size IP 20 (AF-650 GP only)	11	11	11	11	11	11	-	-	-
Unit Size IP 55, 66	15	15	15	15	15	15	15	15	15

#### Output current



Continuous (3 x 200-240 V) [A]	1.8	2.4	3.5	4.6	6.6	7.5	10.6	12.5	16.7
Intermittent (3 x 200-240 V) [A]	2.9	3.8	5.6	7.4	10.6	12.0	17.0	20.0	26.7
Continuous KVA (208 V AC) [kVA]	0.65	0.86	1.26	1.66	2.38	2.70	3.82	4.50	6.00
Max. cable size (mains, motor, brake) [mm <sup>2</sup> (AWG <sup>2</sup> )]					0.2 - 4 (24 - 10)				

#### Max. input current



Continuous (3 x 200-240 V) [A]	1.6	2.2	3.2	4.1	5.9	6.8	9.5	11.3	15.0
Intermittent (3 x 200-240 V) [A]	2.6	3.5	5.1	6.6	9.4	10.9	15.2	18.1	24.0
Max. pre-fuses <sup>1</sup> [A]	10	10	10	10	20	20	20	32	32
Environment									
Estimated power loss at rated max. load [W] <sup>4</sup>	21	29	42	54	63	82	116	155	185
Weight, Unit Size IP20 [kg]	4.7	4.7	4.8	4.8	4.9	4.9	4.9	6.6	6.6
11 (IP20)	2.7	2.7	2.7	2.7	2.7	-	-	-	-
15 (IP55, 66)	13.5	13.5	13.5	13.5	13.5	13.5	13.5	13.5	13.5
Efficiency <sup>4</sup>	0.94	0.94	0.95	0.95	0.96	0.96	0.96	0.96	0.96


0.25 - 3.7 kW only available as 160% high overload.

#### Mains Supply 3 x 200- 240 VAC

AF-650 GP/AF-650 GP


High/ Normal Load*	HO	NO	HO	NO	HO	NO
Typical Shaft Output [kW]	5.5	7.5	7.5	11	11	15
Typical Shaft Output [HP] at 208 V	7.5	10	10	15	15	20
Unit Size IP20		23		23		24
Unit Size IP21		21		21		22
Unit Size IP55, 66		21		21		22

#### Output current



Continuous (3 x 200-240 V) [A]	24.2	30.8	30.8	46.2	46.2	59.4
Intermittent (60 sec overload) (3 x 200-240 V) [A]	38.7	33.9	49.3	50.8	73.9	65.3
Continuous KVA (208 V AC) [kVA]	8.7	11.1	11.1	16.6	16.6	21.4



#### Max. input current



Continuous (3 x 200-240 V) [A]	22	28	28	42	42	54
Intermittent (60 sec overload) (3 x 200-240 V) [A]	35.2	30.8	44.8	46.2	67.2	59.4
Max. cable size [mm <sup>2</sup> (AWG <sup>2</sup> )] <sup>2</sup>	16 (6)		16 (6)		35 (2)	
Max. pre-fuses [A] <sup>1</sup>	63		63		80	
Estimated power loss at rated max. load [W] <sup>4</sup>	239	310	371	514	463	602

\* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s





Mains Supply 3 x 200- 240 VAC											
AF-650 GP/AF-650 GP											
High/ Normal Load*	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO	
Typical Shaft Output [kW]	15	18.5	18.5	22	22	30	30	37	37	45	
Typical Shaft Output [HP] at 208 V	20	25	25	30	30	40	40	50	50	60	
Unit Size IP20		24		33		33		34		34	
Unit Size IP21		31		31		31		32		32	
Unit Size IP55, 66		31		31		31		32		32	
Output current											
 130BA200.10	Continuous (3 x 200-240 V) [A]	59.4	74.8	74.8	88	88	115	115	143	170	
	Intermittent (60 sec overload) (3 x 200-240 V) [A]	89.1	82.3	112	96.8	132	127	173	157	215	187
	Continuous KVA (208 V AC) [KVA]	21.4	26.9	26.9	31.7	31.7	41.4	41.4	51.5	51.5	61.2
Max. input current											
 130BA229.10	Continuous (3 x 200-240 V) [A]	54	68	68	80	80	104	104	130	154	
	Intermittent (60 sec overload) (3 x 200-240 V) [A]	81	74.8	102	88	120	114	156	143	195	169
	Max. cable size, IP20 [mm² (AWG)] <sup>2)</sup>	35 (2)		90 (3/0)		90 (3/0)		120 (4/0)		120 (4/0)	
	Max. cable size, IP21/55/66 [mm² (AWG)] <sup>2)</sup>	90 (3/0)		90 (3/0)		90 (3/0)		120 (4/0)		120 (4/0)	
	Max. pre-fuses [A] <sup>1</sup>	125		125		160		200		250	
	Estimated power loss at rated max. load [W] <sup>4)</sup>	624	737	740	845	874	1140	1143	1353	1400	1636
	Weight, Unit Size IP21, IP 55, 66 [kg]	45		45		45		65		65	
	Efficiency <sup>4)</sup>	0.96		0.97		0.97		0.97		0.97	

5

\* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s





## 5.2 Electrical Data - 380-500 V

Mains Supply 3 x 380 - 500 VAC (AF-650 GP), 3 x 380 - 480 VAC (AF-650 GP)											
AF-650 GP/AF-650 GP	0.37	0.55	0.75	1.1	1.5	2.2	3	4	5.5	7.5	
Typical Shaft Output [kW]											
Typical Shaft Output [HP] at 460V	0.5	0.7	1.0	1.5	2.0	2.9	4.0	5.0	7.5	10	
Unit Size IP20/IP21	12	12	12	12	12	12	12	12	13	13	
Unit Size IP20 (AF-650 GP only)	11	11	11	11	11						
Unit Size IP55, 66	15	15	15	15	15	15	15	15	15	15	
<b>Output current</b>											
<b>High overload 160% for 1 minute</b>											
	Shaft output [kW]	0.37	0.55	0.75	1.1	1.5	2.2	3	4	5.5	7.5
	Continuous (3 x 380-440 V) [A]	1.3	1.8	2.4	3	4.1	5.6	7.2	10	13	16
	Intermittent (3 x 380-440 V) [A]	2.1	2.9	3.8	4.8	6.6	9.0	11.5	16	20.8	25.6
	Continuous (3 x 441-500 V) [A]	1.2	1.6	2.1	2.7	3.4	4.8	6.3	8.2	11	14.5
	Intermittent (3 x 441-500 V) [A]	1.9	2.6	3.4	4.3	5.4	7.7	10.1	13.1	17.6	23.2
	Continuous KVA (400 V AC) [kVA]	0.9	1.3	1.7	2.1	2.8	3.9	5.0	6.9	9.0	11.0
	Continuous KVA (460 V AC) [kVA]	0.9	1.3	1.7	2.4	2.7	3.8	5.0	6.5	8.8	11.6
	Max. cable size (mains, motor, brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]						24 - 10 AWG 0.2 - 4 mm <sup>2</sup>			24 - 10 AWG 0.2 - 4 mm <sup>2</sup>	
<b>Max. input current</b>											
	Continuous (3 x 380-440 V) [A]	1.2	1.6	2.2	2.7	3.7	5.0	6.5	9.0	11.7	14.4
	Intermittent (3 x 380-440 V) [A]	1.9	2.6	3.5	4.3	5.9	8.0	10.4	14.4	18.7	23.0
	Continuous (3 x 441-500 V) [A]	1.0	1.4	1.9	2.7	3.1	4.3	5.7	7.4	9.9	13.0
	Intermittent (3 x 441-500 V) [A]	1.6	2.2	3.0	4.3	5.0	6.9	9.1	11.8	15.8	20.8
	Max. pre-fuses <sup>1)</sup> [A]	10	10	10	10	10	20	20	20	32	32
	Environment										
	Estimated power loss at rated max. load [W] <sup>4)</sup>	35	42	46	58	62	88	116	124	187	255
	Weight, Unit Size IP20	4.7	4.7	4.8	4.8	4.9	4.9	4.9	4.9	6.6	6.6
	Unit Size IP55, 66	13.5	13.5	13.5	13.5	13.5	13.5	13.5	13.5	14.2	14.2
	Efficiency <sup>4)</sup>	0.93	0.95	0.96	0.96	0.97	0.97	0.97	0.97	0.97	0.97



0.37 - 7.5 kW only available as 160% high overload.



Mains Supply 3 x 380 - 500 VAC (AF-650 GP), 3 x 380 - 480 VAC (AF-650 GP)							
AF-650 GP/AF-650 GP		HO	NO	HO	NO	HO	NO
High/ Normal Load*		11	15	15	18.5	18.5	22.0
Typical Shaft output [kW]		23	23	23	24	24	30.0
Typical Shaft Output [HP] at 460 V		15	20	20	25	25	40
Unit Size IP20		21		21		22	
Unit Size IP21						22	
Unit Size IP55, 66		21		21		22	
Output current							
 130BA230.10	Continuous (3 x 380-440 V) [A]	24	32	32	37.5	37.5	44
	Intermittent (60 sec over-load) (3 x 380-440 V) [A]	38.4	35.2	51.2	41.3	60	48.4
	Continuous (3 x 441-500 V) [A]	21	27	27	34	34	40
	Intermittent (60 sec over-load) (3 x 441-500 V) [A]	33.6	29.7	43.2	37.4	54.4	44
	Continuous KVA (400 V AC) [kVA]	16.6	22.2	22.2	26	26	30.5
	Continuous KVA (460 V AC) [kVA]			21.5		27.1	
						31.9	
							41.4
Max. input current							
 130BA229.10	Continuous (3 x 380-440 V) [A]	22	29	29	34	34	40
	Intermittent (60 sec over-load) (3 x 380-440 V) [A]	35.2	31.9	46.4	37.4	54.4	44
	Continuous (3 x 441-500 V) [A]	19	25	25	31	31	36
	Intermittent (60 sec over-load) (3 x 441-500 V) [A]	30.4	27.5	40	34.1	49.6	39.6
	Max. cable size [mm <sup>2</sup> / AWG] <sup>2)</sup>	16/6		16/6		35/2	
	Max. pre-fuses [A] <sup>1)</sup>	63		63		63	
	Estimated power loss at rated max. load [W] <sup>4)</sup>	291	392	379	465	444	525
	Weight, Unit Size IP20	12		12		23.5	
	Weight, Unit Size IP21, IP 55, 66 [kg]	23		23		27	
	Efficiency <sup>4)</sup>	0.98		0.98		0.98	

\* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s





Mains Supply 3 x 380 - 500 VAC (AF-650 GP), 3 x 380 - 480 VAC (AF-650 GP)									
AF-650 GP/AF-650 GP		HO	NO	HO	NO	HO	NO	HO	NO
High/ Normal Load*	Typical Shaft output [kW]	30	37	37	45	45	55	55	75
	Typical Shaft Output [HP] at 460V	40	50	50	60	60	75	75	100
	Unit Size IP20	24		33		33		34	
	Unit Size IP21	31		31		31		32	
	Unit Size IP55, 66	31		31		31		32	
Output current									
 130BA230.10	Continuous (3 x 380-440 V) [A]	61	73	73	90	90	106	106	147
	Intermittent (60 sec overload) (3 x 380-440 V) [A]	91.5	80.3	110	99	135	117	159	162
	Continuous (3 x 441-500 V) [A]	52	65	65	80	80	105	105	130
	Intermittent (60 sec overload) (3 x 441-500 V) [A]	78	71.5	97.5	88	120	116	158	143
	Continuous KVA (400 V AC) [KVA]	42.3	50.6	50.6	62.4	62.4	73.4	73.4	102
	Continuous KVA (460 V AC) [KVA]		51.8		63.7		83.7		104
Max. input current									
 130BA229.10	Continuous (3 x 380-440 V) [A]	55	66	66	82	82	96	96	133
	Intermittent (60 sec overload) (3 x 380-440 V) [A]	82.5	72.6	99	90.2	123	106	144	146
	Continuous (3 x 441-500 V) [A]	47	59	59	73	73	95	95	118
	Intermittent (60 sec overload) (3 x 441-500 V) [A]	70.5	64.9	88.5	80.3	110	105	143	130
	Max. cable size IP20, mains and motor [mm <sup>2</sup> (AWG <sup>2</sup> )]	35 (2)		50 (1)		50 (1)		95 (4/0)	150 (300mcm)
	Max. cable size IP20, load share and brake [mm <sup>2</sup> (AWG <sup>2</sup> )]	35 (2)		50 (1)		50 (1)		95 (4/0)	95 (4/0)
	Max. cable size, IP21/55/66 [mm <sup>2</sup> (AWG <sup>2</sup> )]	90 (3/0)		90 (3/0)		90 (3/0)		120 (4/0)	120 (4/0)
	Max. pre-fuses [A] <sup>1</sup>	100		125		160		250	250
	Estimated power loss at rated max. load [W] <sup>4)</sup>	570	698	697	843	891	1083	1022	1384
	Weight, Unit Size IP21, IP 55, 66 [kg]	45		45		45		65	65
	Efficiency <sup>4)</sup>	0.98		0.98		0.98		0.98	0.99

\* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s



## 5.3 Electrical Data - 525-600 V


5

Mains Supply 3 x 525 - 600 VAC (AF-650 GP only)									
AF-650 GP	Typical Shaft Output [kW]	0.75	1.1	1.5	2.2	3	4	5.5	7.5
	Typical Shaft Output [HP] at 575V	1.0	1.5	2.0	2.9	4.0	5.0	7.5	10
	Unit Size IP20, 21	12	12	12	12	12	12	13	13
	Unit Size IP55	15	15	15	15	15	15	15	15
Output current	Continuous (3 x 525-550 V) [A]	1.8	2.6	2.9	4.1	5.2	6.4	9.5	11.5
 13804052-10	Intermittent (3 x 525-550 V) [A]	2.9	4.2	4.6	6.6	8.3	10.2	15.2	18.4
	Continuous (3 x 551-600 V) [A]	1.7	2.4	2.7	3.9	4.9	6.1	9.0	11.0
	Intermittent (3 x 551-600 V) [A]	2.7	3.8	4.3	6.2	7.8	9.8	14.4	17.6
	Continuous kVA (525 V AC) [kVA]	1.7	2.5	2.8	3.9	5.0	6.1	9.0	11.0
	Continuous kVA (575 V AC) [kVA]	1.7	2.4	2.7	3.9	4.9	6.1	9.0	11.0
	Max. cable size (mains, motor, brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]	24 - 10 AWG 0.2 - 4 mm <sup>2</sup>				24 - 10 AWG 0.2 - 4 mm <sup>2</sup>			
Max. input current	Continuous (3 x 525-600 V) [A]	1.7	2.4	2.7	4.1	5.2	5.8	8.6	10.4
 13804052-10	Intermittent (3 x 525-600 V) [A]	2.7	3.8	4.3	6.6	8.3	9.3	13.8	16.6
	Max. pre-fuses <sup>1)</sup> [A]	10	10	10	20	20	20	32	32
Environment	Estimated power loss at rated max. load [W] <sup>4)</sup>	35	50	65	92	122	145	195	261
	Weight, Unit Size IP20 [kg]	6.5	6.5	6.5	6.5	6.5	6.5	6.6	6.6
	Weight, Unit Size IP55 [kg]	13.5	13.5	13.5	13.5	13.5	13.5	14.2	14.2
	Efficiency <sup>4)</sup>	0.97	0.97	0.97	0.97	0.97	0.97	0.97	0.97



Mains Supply 3 x 525 - 600 VAC										
AF-650 GP										
High/ Normal Load*	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO
Typical Shaft Output [kW]	11	15	15	18.5	18.5	22	22	30	30	37
Typical Shaft Output [HP] at 575V	15	20	20	25	25	30	30	40	40	50
Unit Size IP 21, 55, 66	21		21		22		22		31	
Unit Size IP20	23		23		24		24		24	
Output current										
Continuous (3 x 525-550 V) [A]	19	23	23	28	28	36	36	43	43	54
Intermittent (3 x 525-550 V) [A]	30	25	37	31	45	40	58	47	65	59
Continuous (3 x 525-600 V) [A]	18	22	22	27	27	34	34	41	41	52
Intermittent (3 x 525-600 V) [A]	29	24	35	30	43	37	54	45	62	57
Continuous kVA (550 V AC) [kVA]	18.1	21.9	21.9	26.7	26.7	34.3	34.3	41.0	41.0	51.4
Continuous kVA (575 V AC) [kVA]	17.9	21.9	21.9	26.9	26.9	33.9	33.9	40.8	40.8	51.8
Max. cable size IP20 (mains, motor, load share and brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]			16(6)					35(2)		
Max. cable size IP21, 55, 66 (mains, motor, load share and brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]			16(6)				35(2)			90 (3/0)
Max. input current										
Continuous at 550 V [A]	17.2	20.9	20.9	25.4	25.4	32.7	32.7	39	39	49
Intermittent at 550 V [A]	28	23	33	28	41	36	52	43	59	54
Continuous at 575 V [A]	16	20	20	24	24	31	31	37	37	47
Intermittent at 575 V [A]	26	22	32	27	39	34	50	41	56	52
Max. pre-fuses <sup>1)</sup> [A]	63		63		63		80			100
Environment										
Estimated power loss at rated max. load [W] <sup>4)</sup>		225		285		329		700		700
Weight, Unit Size IP21, 55 [kg]		23		23		27		27		27
Weight, Unit Size IP20 [kg]		12		12		23.5		23.5		23.5
Efficiency <sup>4)</sup>		0.98		0.98		0.98		0.98		0.98



Mains Supply 3 x 525 - 600 VAC							
AF-650 GP		HO	NO	HO	NO	HO	NO
High/ Normal Load*							
Typical Shaft Output [kW]	37	45	45	55	55	75	75
Typical Shaft Output [HP] at 575V	50	60	60	74	74	100	100
Unit Size IP21, 55, 66	31	31	31		32		32
Unit Size IP20	33	33	33		34		34
Output current							
 Continuous (3 x 525-550 V) [A]	54	65	65	87	87	105	105
Intermittent (3 x 525-550 V) [A]	81	72	98	96	131	116	158
Continuous (3 x 525-600 V) [A]	52	62	62	83	83	100	100
Intermittent (3 x 525-600 V) [A]	78	68	93	91	125	110	150
Continuous kVA (550 V AC) [kVA]	51.4	61.9	61.9	82.9	82.9	100.0	100.0
Continuous kVA (575 V AC) [kVA]	51.8	61.7	61.7	82.7	82.7	99.6	130.5
Max. cable size IP20 (mains, motor) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]			50 (1)		95 (4/0)		150 (300mcm)
Max. cable size IP20 (load share, brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]			50 (1)		95 (4/0)		
Max. cable size IP21, 55, 66 (mains, motor, load share and brake) [AWG] <sup>2)</sup> [mm <sup>2</sup> ]			90 (3/0)		120 (4/0)		
Max. input current							
 Continuous at 550 V [A]	49	59	59	78.9	78.9	95.3	95.3
Intermittent at 550 V [A]	74	65	89	87	118	105	143
Continuous at 575 V [A]	47	56	56	75	75	91	91
Intermittent at 575 V [A]	70	62	85	83	113	100	137
Max. pre-fuses <sup>1)</sup> [A]	125		160		250		250
Environment							
Estimated power loss at rated max. load [W] <sup>4)</sup>		850		1100		1400	
Weight, Unit Size IP20 [kg]		35		35		50	
Weight, Unit Size IP21, 55 [kg]		45		45		65	
Efficiency <sup>4)</sup>	0.98		0.98		0.98		0.98



## Mains supply (L1, L2, L3):

Supply voltage	200-240 V ±10%
Supply voltage	380-500 V ±10%
Supply voltage	525-690 V ±10%
Supply frequency	50/60 Hz
Max. imbalance temporary between mains phases	3.0 % of rated supply voltage
True Power Factor ( $\lambda$ )	≥ 0.9 nominal at rated load
Displacement Power Factor ( $\cos \phi$ )	near unity (> 0.98)
Switching on input supply L1, L2, L3 (power-ups) ≤ 7.5 kW	maximum 2 times/min.
Switching on input supply L1, L2, L3 (power-ups) 11-75 kW	maximum 1 time/min.
Switching on input supply L1, L2, L3 (power-ups) ≥ 90 kW	maximum 1 time/2 min.
Environment according to EN60664-1	overvoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100,000 RMS symmetrical Amperes, 240/500/600/ 690 V maximum.

5

## Motor output (U, V, W):

Output voltage	0 - 100% of supply voltage
Output frequency (0.25-75 kW)	0 - 1000 Hz
Output frequency (90-1000 kW)	0 - 800* Hz
Output frequency in Flux Mode	0 - 300 Hz
Switching on output	Unlimited
Ramp times	0.01 - 3600 sec.

\* Voltage and power dependent

## Torque characteristics:

Starting torque (Constant torque)	maximum 160% for 60 sec.*
Starting torque	maximum 180% up to 0.5 sec.*
Overload torque (Constant torque)	maximum 160% for 60 sec.*
Starting torque (Variable torque)	maximum 110% for 60 sec.*
Overload torque (Variable torque)	maximum 110% for 60 sec.

\*Percentage relates to the nominal torque.

## Digital inputs:

Programmable digital inputs	4 (6)
Terminal number	18, 19, 27 <sup>1</sup> , 29 <sup>1</sup> , 32, 33,
Logic	PNP or NPN
Voltage level	0 - 24 V DC
Voltage level, logic '0' PNP	< 5 V DC
Voltage level, logic '1' PNP	> 10 V DC
Voltage level, logic '0' NPN <sup>2</sup>	> 19 V DC
Voltage level, logic '1' NPN <sup>2</sup>	< 14 V DC
Maximum voltage on input	28 V DC
Pulse frequency range	0 - 110 kHz
(Duty cycle) Min. pulse width	4.5 ms
Input resistance, R <sub>i</sub>	approx. 4 kΩ



Safe stop Terminal 37<sup>2)</sup> (Terminal 37 is fixed PNP logic):

Voltage level	0 - 24 V DC
Voltage level, logic'0' PNP	< 4 V DC
Voltage level, logic'1' PNP	> 20 V DC
Nominal input current at 24 V	50 mA rms
Nominal input current at 20 V	60 mA rms
Input capacitance	400 nF

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as output.


2) Terminal 37 is only available in AF-650 GP. It can only be used as safe stop input. Terminal 37 is suitable for category 3 installations according to EN 954-1 (safe stop according to category 0 EN 60204-1) as required by the EU Machinery Directive 98/37/EC. Terminal 37 and the Safe Stop function are designed in conformance with EN 60204-1, EN 50178, EN 61800-2, EN 61800-3, and EN 954-1. For correct and safe use of the Safe Stop function follow the related information and instructions in the AF-650 GP Design Guide.

## 5

Analog inputs:

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switch S201 and switch S202
Voltage mode	Switch S201/switch S202 = OFF (U)
Voltage level	-10 to +10 V (scaleable)
Input resistance, R <sub>i</sub>	approx. 10 kΩ
Max. voltage	± 20 V
Current mode	Switch S201/switch S202 = ON (I)
Current level	0/4 to 20 mA (scaleable)
Input resistance, R <sub>i</sub>	approx. 200 Ω
Max. current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Max. error 0.5% of full scale
Bandwidth	100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.





## Pulse/encoder inputs:

Programmable pulse/encoder inputs	2/1
Terminal number pulse/encoder	29, 33 <sup>1)</sup> / 32 <sup>2)</sup> , 33 <sup>2)</sup>
Max. frequency at terminal 29, 32, 33	110 kHz (Push-pull driven)
Max. frequency at terminal 29, 32, 33	5 kHz (open collector)
Min. frequency at terminal 29, 32, 33	4 Hz
Voltage level	see section on Digital input
Maximum voltage on input	28 V DC
Input resistance, R	approx. 4 kΩ
Pulse input accuracy (0.1 - 1 kHz)	Max. error: 0.1% of full scale
Encoder input accuracy (1 - 110 kHz)	Max. error: 0.05 % of full scale

The pulse and encoder inputs (terminals 29, 32, 33) are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Pulse inputs are 29 and 33

2) Encoder inputs: 32 = A, and 33 = B

5

## Digital output:

Programmable digital/pulse outputs	2
Terminal number	27, 29 <sup>1)</sup>
Voltage level at digital/frequency output	0 - 24 V
Max. output current (sink or source)	40 mA
Max. load at frequency output	1 kΩ
Max. capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Max. error: 0.1 % of full scale
Resolution of frequency outputs	12 bit

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

## Analog output:

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4 - 20 mA
Max. load GND - analog output	500 Ω
Accuracy on analog output	Max. error: 0.5 % of full scale
Resolution on analog output	12 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

## Control card, 24 V DC output:

Terminal number	12, 13
Output voltage	24 V +1, -3 V
Max. load	200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

## Control card, 10 V DC output:

Terminal number	50
Output voltage	10.5 V ± 0.5 V
Max. load	15 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.



Control card, RS 485 serial communication:

Terminal number	68 (P,TX+, RX+), 69 (N,TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS 485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Control card, USB serial communication:

USB standard	1.1 (Full speed)
USB plug	USB type B "device" plug

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

The USB ground connection is not galvanically isolated from protection earth. Use only an isolated laptop as PC connection to the USB connector on the frequency converter.

## 5

Relay outputs:

Programmable relay outputs	2 Form C
Relay 01 Terminal number	1-3 (break), 1-2 (make)
Max. terminal load (AC-1) <sup>1)</sup> on 1-3 (NC), 1-2 (NO) (Resistive load)	240 V AC, 2 A
Max. terminal load (AC-15) <sup>1)</sup> (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) <sup>1)</sup> on 1-2 (NO), 1-3 (NC) (Resistive load)	60 V DC, 1A
Max. terminal load (DC-13) <sup>1)</sup> (Inductive load)	24 V DC, 0.1A
Relay 02 Terminal number	4-6 (break), 4-5 (make)
Max. terminal load (AC-1) <sup>1)</sup> on 4-5 (NO) (Resistive load) <sup>2)</sup> <sup>3)</sup> Overvoltage cat. II	400 V AC, 2 A
Max. terminal load (AC-15) <sup>1)</sup> on 4-5 (NO) (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) <sup>1)</sup> on 4-5 (NO) (Resistive load)	80 V DC, 2 A
Max. terminal load (DC-13) <sup>1)</sup> on 4-5 (NO) (Inductive load)	24 V DC, 0.1A
Max. terminal load (AC-1) <sup>1)</sup> on 4-6 (NC) (Resistive load)	240 V AC, 2 A
Max. terminal load (AC-15) <sup>1)</sup> on 4-6 (NC) (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) <sup>1)</sup> on 4-6 (NC) (Resistive load)	50 V DC, 2 A
Max. terminal load (DC-13) <sup>1)</sup> on 4-6 (NC) (Inductive load)	24 V DC, 0.1 A
Min. terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO)	24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	overvoltage category III/pollution degree 2

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II

3) UL applications 300 V AC 2A

Cable lengths and cross sections for control cables\*:

Max. motor cable length, screened	150 m
Max. motor cable length, unshielded	300 m
Maximum cross section to control terminals, flexible/ rigid wire without cable end sleeves	1.5 mm <sup>2</sup> /16 AWG
Maximum cross section to control terminals, flexible wire with cable end sleeves	1 mm <sup>2</sup> /18 AWG
Maximum cross section to control terminals, flexible wire with cable end sleeves with collar	0.5 mm <sup>2</sup> /20 AWG
Minimum cross section to control terminals	0.25 mm <sup>2</sup> / 24 AWG

\* Power cables, see tables in section "Electrical Data" of the AF-650 GP Design Guide



## Control card performance:

Scan interval

AF-650 GP: 1 ms

## Control characteristics:

Resolution of output frequency at 0 - 1000 Hz	+/- 0.003 Hz
Repeat accuracy of Precise start/stop (terminals 18, 19)	$\leq \pm 0.1$ msec
System response time (terminals 18, 19, 27, 29, 32, 33)	$\leq 2$ ms
Speed control range (open loop)	1:100 of synchronous speed
Speed control range (closed loop)	1:1000 of synchronous speed
Speed accuracy (open loop)	30 - 4000 rpm: error $\pm 8$ rpm
Speed accuracy (closed loop), depending on resolution of feedback device	0 - 6000 rpm: error $\pm 0.15$ rpm

*All control characteristics are based on a 4-pole asynchronous motor*

## Surroundings:

Enclosure	IP20 Open Chassis, Nema 1 with field installed kit, Nema 12, and Nema 4
Vibration test	1.0 g
Max. relative humidity	5% - 93% (IEC 721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 60068-2-43) H <sub>2</sub> S test	class Kd
Ambient temperature	Max. 50 °C

1) Only for  $\leq 3.7$  kW (200 - 240 V),  $\leq 7.5$  kW (400 - 480/ 500 V)2) As enclosure kit for  $\leq 3.7$  kW (200 - 240 V),  $\leq 7.5$  kW (400 - 480/ 500 V)

3) Derating for high ambient temperature, see special conditions in the Design Guide

Minimum ambient temperature during full-scale operation	0 °C
Minimum ambient temperature at reduced performance	- 10 °C
Temperature during storage/transport	-25 - +65/70 °C
Maximum altitude above sea level without derating	1000 m

Derating for high altitude, see special conditions in the Design Guide

EMC standards, Emission	EN 61800-3, EN 61000-6-3/4, EN 55011 EN 61800-3, EN 61000-6-1/2,
EMC standards, Immunity	EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6

See section on special conditions in the Design Guide. Please see [www.geelectrical.com/drives](http://www.geelectrical.com/drives) for more information.

## Protection and Features:

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heatsink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heatsink is below the values stated in the tables on the following pages (Guideline - these temperatures may vary for different power sizes, Unit Sizes, enclosure ratings etc.).
- The frequency converter is protected against short-circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips if the intermediate circuit voltage is too low or too high.
- The frequency converter constantly checks for critical levels of internal temperature, load current, high voltage on the intermediate circuit and low motor speeds. As a response to a critical level, the frequency converter can adjust the switching frequency and/ or change the switching pattern in order to ensure the performance of the drive.



# 6



## 6 Troubleshooting

### 6.1.1 Warnings/Alarm Messages

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the frequency converter will have tripped. Alarms must be reset to restart operation once their cause has been rectified.

**This may be done in three ways:**

1. By using the [RESET] control button on the Keypad control panel.
2. Via a digital input with the "Reset" function.
3. Via serial communication/optional network.

**NB!**

After a manual reset using the [RESET] button on the Keypad, the [AUTO] button must be pressed to restart the motor.

6

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also table on following page).

Alarms that are trip-locked offer additional protection, meaning that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in par. H-04 Auto-Reset (*Times*) (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the table on the following page, this means that either a warning occurs before an alarm, or else that you can specify whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in par. F-10 *Electronic Overload*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash. Once the problem has been rectified, only the alarm continues flashing until the frequency converter is reset.



No.	Description	Warning	Alarm/Trip	Alarm/Trip Lock	Parameter Reference
1	10 Volts low	X			
2	Live zero error	(X)	(X)		par. AN-01 Live Zero Time-out Function
3	No motor	(X)			par. H-80 Function at Stop
4	Mains phase loss	(X)	(X)	(X)	par. SP-12 Function at Line Imbalance
5	DC link voltage high	X			
6	DC link voltage low	X			
7	DC over-voltage	X	X		
8	DC under voltage	X	X		
9	Inverter overloaded	X	X		
10	Motor Electronic OL over temperature	(X)	(X)		par. F-10 Electronic Overload
11	Motor thermistor over temperature	(X)	(X)		par. F-10 Electronic Overload
12	Torque limit	X	X		
13	Over Current	X	X	X	
14	Earth Fault	X	X	X	
15	Hardware mismatch	X	X		
16	Short Circuit	X	X	X	
17	Control word time-out	(X)	(X)		par. O-04 Control Word Timeout Function
22	Hoist Mech. Brake				
23	Internal Fan Fault	X			
24	External Fan Fault	X			par. SP-53 Fan Monitor
25	Brake resistor short-circuited	X			
26	Brake resistor power limit	(X)	(X)		par. B-13 Braking Thermal Overload
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		par. B-15 Brake Check
29	Heatsink temp	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	par. H-78 Missing Motor Phase Function
31	Motor phase V missing	(X)	(X)	(X)	par. H-78 Missing Motor Phase Function
32	Motor phase W missing	(X)	(X)	(X)	par. H-78 Missing Motor Phase Function
33	Inrush Fault	X	X		
34	Network communication fault	X	X		
36	Mains failure	X	X		
38	Internal Fault	X	X	X	
39	Heatsink sensor	X	X	X	
40	Overload of Digital Output Terminal 27	(X)			par. E-00 Digital I/O Mode, par. E-51 Terminal 27 Mode
41	Overload of Digital Output Terminal 29	(X)			par. E-00 Digital I/O Mode, par. E-52 Terminal 29 Mode
42	Overload of Digital Output On X30/6	(X)			par. E-56 Term X30/6 Digi Out (OPCGPIO)
42	Overload of Digital Output On X30/7	(X)			par. E-57 Term X30/7 Digi Out (OPCGPIO)
46	Pwr. card supply	X	X	X	
47	24 V supply low	X	X	X	
48	1.8 V supply low	X	X	X	
49	Speed limit	X			
50	Auto Tune calibration failed	X			
51	Auto Tune check $U_{nom}$ and $I_{nom}$	X			
52	Auto Tune low $I_{nom}$	X			
53	Auto Tune motor too big	X			

Table 6.1: Alarm/Warning code list



No.	Description	Warning	Alarm/Trip	Alarm/Trip Lock	Parameter Reference
54	Auto Tune motor too small		X		
55	Auto Tune parameter out of range		X		
56	Auto Tune interrupted by user		X		
57	Auto Tune time-out		X		
58	Auto Tune internal fault	X	X		
59	Current limit	X			
61	Tracking Error	(X)	(X)		par. H-20 Motor Feedback Loss Function
62	Output Frequency at Maximum Limit	X			
63	Mechanical Brake Low		(X)		par. B-20 Release Brake Current
64	Voltage Limit	X			
65	Control Board Over-temperature	X	X	X	
66	Heat sink Temperature Low	X			
67	Option Module Configuration has Changed		X		
68	Safe Stop	(X)	(X) <sup>1)</sup>		par. E-07 Terminal 37 Safe Stop
69	Pwr. Card Temp		X	X	
70	Illegal Drive configuration			X	
71	Safe Stop	X	X <sup>1)</sup>		par. E-07 Terminal 37 Safe Stop
72	Dangerous Failure			X <sup>1)</sup>	par. E-07 Terminal 37 Safe Stop
73	Safe Stop Auto Restart				
77	Reduced power mode	X			par. SP-59 Actual Number of Inverter Units
79	Illegal PS config	X		X	
80	Drive Restored to Factory Settings		X		
81	CSIV corrupt				
82	CSIV parameter error				
85	Profibus/Profisafe Error				
90	Encoder Loss	(X)	(X)		par. EC-61 Feedback Signal Monitoring S202
91	Analog input 54 wrong settings			X	
243	Brake IGBT	X	X		
244	Heatsink temp	X	X	X	
245	Heatsink sensor		X	X	
246	Pwr.card supply	X		X	
247	Pwr.card temp	X		X	
248	Illegal PS config	X		X	
250	New spare part			X	
251	New Model Number		X	X	

Table 6.2: Alarm/Warning code list

(X) Dependent on parameter

1) Can not be Auto reset via par. H-04 Auto-Reset (Times)

A trip is the action when an alarm has appeared. The trip will coast the motor and can be reset by pressing the reset button or make a reset by a digital input (Par. E-1# [1]). The origin event that caused an alarm cannot damage the frequency converter or cause dangerous conditions. A trip lock is an action when an alarm occurs, which may cause damage to frequency converter or connected parts. A Trip Lock situation can only be reset by a power cycling.

LED indication	
Warning	yellow
Alarm	flashing red
Trip locked	yellow and red



Alarm Word Extended Status Word							
Bit	Hex	Dec	Alarm Word	Alarm Word 2	Warning Word	Warning Word 2	Extended Status Word
0	00000001	1	Brake Check	ServiceTrip, Write	Read/ Brake Check		Ramping
1	00000002	2	Pwr. Card Temp	ServiceTrip, served)	(re- Pwr. Card Temp		Auto Tune Running
2	00000004	4	Earth Fault	ServiceTrip, code/Sparepart	Type- Earth Fault		Start CW/CCW
3	00000008	8	Ctrl.Card Temp	ServiceTrip, served)	(re- Ctrl.Card Temp		Slow Down
4	00000010	16	Ctrl. Word TO	ServiceTrip, served)	(re- Ctrl. Word TO		Catch Up
5	00000020	32	Over Current		Over Current		Feedback High
6	00000040	64	Torque Limit		Torque Limit		Feedback Low
7	00000080	128	Motor Th Over		Motor Th Over		Output Current High
8	00000100	256	Motor Electronic OL Over		Motor Electronic OL Over		Output Current Low
9	00000200	512	Drive Overld.		Drive Overld.		Output Freq High
10	00000400	1024	DC under Volt		DC under Volt		Output Freq Low
11	00000800	2048	DC over Volt		DC over Volt		Brake Check OK
12	00001000	4096	Short Circuit		DC Voltage Low		Braking Max
13	00002000	8192	Inrush Fault		DC Voltage High		Braking
14	00004000	16384	Mains ph. Loss		Mains ph. Loss		Out of Speed Range
15	00008000	32768	Auto Tune Not OK		No Motor		OVC Active
16	00010000	65536	Live Zero Error		Live Zero Error		AC Brake
17	00020000	131072	Internal Fault	KTY error	10V Low	KTY Warn	Password Timelock
18	00040000	262144	Brake Overload	Fans error	Brake Overload	Fans Warn	Password Protection
19	00080000	524288	U phase Loss	ECB error	Brake Resistor	ECB Warn	
20	00100000	1048576	V phase Loss		Brake IGBT		
21	00200000	2097152	W phase Loss		Speed Limit		
22	00400000	4194304	Network Fault		Network Fault		Unused
23	00800000	8388608	24 V Supply Low		24V Supply Low		Unused
24	01000000	16777216	Mains Failure		Mains Failure		Unused
25	02000000	33554432	1.8V Supply Low		Current Limit		Unused
26	04000000	67108864	Brake Resistor		Low Temp		Unused
27	08000000	134217728	Brake IGBT		Voltage Limit		Unused
28	10000000	268435456	Option Change		Encoder loss		Unused
29	20000000	536870912	Drive Restored to factory settings		Output freq. lim.		Unused
30	40000000	1073741824	Safe Stop (A68)	Safe Stop (A71)	Safe Stop (W68)	Safe Stop (W71)	Unused
31	80000000	2147483648	Mech. brake low	Dangerous Failure	Extended Status Word (A72)		Unused

Table 6.3: Description of Alarm Word, Warning Word and Extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional network for diagnose. See alsopar. DR-94 Ext. Status Word.

#### **WARNING 1, 10 Volts low:**

The 10 V voltage from terminal 50 on the control card is below 10 V.

Remove some of the load from terminal 50, as the 10 V supply is overloaded.

Max. 15 mA or minimum 590 Ω.

#### **WARNING/ALARM 2, Live zero error:**

The signal on terminal 53 or 54 is less than 50% of the value set in par.

AN-10 Terminal 53 Low Voltage, par. AN-12 Terminal 53 Low Current, par.

AN-20 Terminal 54 Low Voltage, or par. AN-22 Terminal 54 Low Current respectively.

#### **WARNING/ALARM 3, No motor:**

No motor has been connected to the output of the frequency converter.

#### **WARNING/ALARM 4, Mains phase loss:**

A phase is missing on the supply side, or the mains voltage imbalance is too high.

This message also appears in case of a fault in the input rectifier on the frequency converter.

Check the supply voltage and supply currents to the frequency converter.

#### **WARNING 5, DC link voltage high:**

The intermediate circuit voltage (DC) is higher than the overvoltage limit of the control system. The frequency converter is still active.

#### **WARNING 6, DC link voltage low**

The intermediate circuit voltage (DC) is below the undervoltage limit of the control system. The frequency converter is still active.

#### **WARNING/ALARM 7, DC over voltage:**

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

#### **Possible corrections:**

Connect a brake resistor

Extend the ramp time

Activate functions in par. B-10 Brake Function

Increase par. SP-26 Trip Delay at Drive Fault

**Alarm/warning limits:**

	3 x 200 - 240 V [VDC]	3 x 380 - 500 V [VDC]	3 x 525 - 600 V [VDC]
Undervoltage	185	373	532
Voltage warning low	205	410	585
Voltage warning high (w/o brake - w/ brake)	390/405	810/840	943/965
Overtension	410	855	975

The voltages stated are the intermediate circuit voltage of the frequency converter with a tolerance of  $\pm 5\%$ . The corresponding mains voltage is the intermediate circuit voltage (DC-link) divided by 1.35

**WARNING/ALARM 8, DC under voltage:**

If the intermediate circuit voltage (DC) drops below the "voltage warning low" limit (see table above), the frequency converter checks if 24 V backup supply is connected.

If no 24 V backup supply is connected, the frequency converter trips after a given time depending on the unit.

To check whether the supply voltage matches the frequency converter, see *General Specifications*.

**WARNING/ALARM 9, Drive overloaded:**

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. You cannot reset the frequency converter until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than 100% for too long.

**WARNING/ALARM 10, Motor electronic overload over temperature:**

According to the electronic thermal protection, the motor is too hot. You can choose if you want the frequency converter to give a warning or an alarm when the counter reaches 100% in par. F-10 *Electronic Overload*. The fault is that the motor is overloaded by more than 100% for too long. Check that the motor par. P-03 *Motor Current* is set correctly.

**WARNING/ALARM 11, Motor thermistor over temp:**

The thermistor or the thermistor connection is disconnected. You can choose if you want the frequency converter to give a warning or an alarm when the counter reaches 100% in par. F-10 *Electronic Overload*. Check that the thermistor is connected correctly between terminal 53 or 54 (analog voltage input) and terminal 50 (+ 10 V supply), or between terminal 18 or 19 (digital input PNP only) and terminal 50. If a KTY sensor is used, check for correct connection between terminal 54 and 55.

**WARNING/ALARM 12, Torque limit:**

The torque is higher than the value in par. F-40 *Torque Limiter (Driving)* (in motor operation) or the torque is higher than the value in par. F-41 *Torque Limiter (Braking)* (in regenerative operation).

**WARNING/ALARM 13, Over Current:**

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 sec., then the frequency converter trips and issues an alarm. Turn off the frequency converter and check if the motor shaft can be turned and if the motor size matches the frequency converter.

If extended mechanical brake control is selected, trip can be reset externally.

**ALARM 14, Earth fault:**

There is a discharge from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself.

Turn off the frequency converter and remove the earth fault.

**ALARM 15, Incomplete hardware:**

A fitted option is not handled by the present control board (hardware or software).

**ALARM 16, Short-circuit**

There is short-circuiting in the motor or on the motor terminals.

Turn off the frequency converter and remove the short-circuit.

**WARNING/ALARM 17, Control word timeout:**

There is no communication to the frequency converter.

The warning will only be active when par. O-04 *Control Word Timeout Function* is NOT set to OFF.

If par. O-04 *Control Word Timeout Function* is set to Stop and Trip, a warning appears and the frequency converter ramps down until it trips, while giving an alarm.

par. O-03 *Control Word Timeout Time* could possibly be increased.

**WARNING 23, Internal fan fault:**

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in par. SP-53 *Fan Monitor* (set to [0] Disabled).

**WARNING 24, External fan fault:**

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in par. SP-53 *Fan Monitor* (set to [0] Disabled).

**WARNING 25, Brake resistor short-circuited:**

The brake resistor is monitored during operation. If it short-circuits, the brake function is disconnected and the warning appears. The frequency converter still works, but without the brake function. Turn off the frequency converter and replace the brake resistor (see par. B-15 *Brake Check*).

**ALARM/WARNING 26, Brake resistor power limit:**

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 s, on the basis of the resistance value of the brake resistor (par. B-11 *Brake Resistor (ohm)*) and the intermediate circuit voltage. The warning is active when the dissipated braking power is higher than 90%. If *Trip* [2] has been selected in par. B-13 *Braking Thermal Overload*, the frequency converter cuts out and issues this alarm, when the dissipated braking power is higher than 100%.

**ALARM/WARNING 27, Brake chopper fault:**

The brake transistor is monitored during operation and if it short-circuits, the brake function disconnects and the warning comes up. The frequency converter is still able to run, but since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

Turn off the frequency converter and remove the brake resistor.

This alarm/warning could also occur should the brake resistor overheat. Terminal 104 to 106 are available as brake resistor. Klixon inputs, see section *Brake Resistor Temperature Switch*.



Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short-circuited.

**ALARM/WARNING 28, Brake check failed:**

Brake resistor fault: the brake resistor is not connected/working.

**ALARM 29, Drive over temperature:**

If the drive type is IP20 Open Chassis, IP20 with Nema 1 kit, or Nema 1 the cut-out temperature of the heat-sink is  $95^{\circ}\text{C} \pm 5^{\circ}\text{C}$ . The temperature fault cannot be reset, until the temperature of the heatsink is below  $70^{\circ}\text{C} \pm 5^{\circ}\text{C}$ .

**The fault could be:**

- Ambient temperature too high
- Too long motor cable

**ALARM 30, Motor phase U missing:**

Motor phase U between the frequency converter and the motor is missing.  
Turn off the frequency converter and check motor phase U.

**ALARM 31, Motor phase V missing:**

Motor phase V between the frequency converter and the motor is missing.  
Turn off the frequency converter and check motor phase V.

**ALARM 32, Motor phase W missing:**

Motor phase W between the frequency converter and the motor is missing.  
Turn off the frequency converter and check motor phase W.

**ALARM 33, Inrush fault:**

Too many power ups have occurred within a short time period. See the chapter *General Specifications* for the allowed number of power ups within one minute.

**6****WARNING/ALARM 34, Network communication fault:**

The network option card is not working correctly. Please check parameters associated with the module and make sure module is properly inserted in Slot A of the drive.

**WARNING/ALARM 36, Mains failure:**

This warning/alarm is only active if the supply voltage to the frequency converter is lost and par. SP-10 Line failure is NOT set to OFF. Possible correction: check the fuses/circuit breaker connected to the frequency converter

**ALARM 38, Internal fault:**

Internal drive fault. Please contact your GE supplier. Some typical alarm messages:

- 0 The serial port cannot be initialized. Serious hardware failure
- 256 The power EEPROM data is defected or outdated.
- 512 The control board EEPROM data is defected or outdated.
- 513 Communication time out Reading EEPROM data
- 514 Communication time out Reading EEPROM data
- 515 The Application Orientated Control cannot recognize the EEPROM data
- 516 Cannot write write to the EEPROM because a write command is in progress
- 517 The write command is under time out
- 518 Failure in the EEPROM
- 519 Missing or invalid BarCode data in EEPROM 1024 – 1279 CAN telegram cannot be sent. (1027 indicate a possible hardware failure)
- 1281 Digital Signal Processor flash time-out
- 1282 Power micro software version mismatch
- 1283 Power EEPROM data version mismatch
- 1284 Cannot read Digital Signal Processor software version
- 1299 Option SW in slot A is outdated
- 1300 Option SW in slot B is outdated
- 1311 Option SW in slot C0 is outdated
- 1312 Option SW in slot C1 is outdated
- 1315 Option SW in slot A is not supported (not allowed)
- 1316 Option SW in slot B is not supported (not allowed)
- 1317 Option SW in slot C0 is not supported (not allowed)
- 1318 Option SW in slot C1 is not supported (not allowed)
- 1536 An exception in the Application Orientated Control is registered. Debug information written in Keypad
- 1792 DSP watchdog is active. Debugging of power part data Motor Orientated Control data not transferred correctly
- 2049 Power data restarted
- 2315 Missing SW version from power unit
- 2816 Stack overflow Control board module
- 2817 Scheduler slow tasks
- 2818 Fast tasks
- 2819 Parameter thread
- 2820 Keypad stack overflow

2821	Serial port overflow
2822	USB port overflow
3072-512	Parameter value is outside its limits. Perform a initialization.
2	Parameter number causing the alarm: Subtract the code from 3072. Ex Error code 3238: 3238-3072 = 166 is outside the limit
5123	Option in slot A: Hardware incompatible with Control board hardware
5124	Option in slot B: Hardware incompatible with Control board hardware
5125	Option in slot C0: Hardware incompatible with Control board hardware
5126	Option in slot C1: Hardware incompatible with Control board hardware
5376-623	Out of memory
1	

**WARNING 40, Overload of Digital Output Terminal 27**

Check the load connected to terminal 27 or remove short-circuit connection.  
Check par. E-00 Digital I/O Mode and par. E-51 Terminal 27 Mode.

**WARNING 41, Overload of Digital Output Terminal 29:**

Check the load connected to terminal 29 or remove short-circuit connection.  
Check par. E-00 Digital I/O Mode and par. E-52 Terminal 29 Mode.

**WARNING 42, Overload of Digital Output On X30/6:**

Check the load connected to X30/6 or remove short-circuit connection. Check par. E-56 Term X30/6 Digi Out (OPCGPIO).

**WARNING 42, Overload of Digital Output On X30/7 :**

Check the load connected to X30/7 or remove short-circuit connection. Check par. E-57 Term X30/7 Digi Out (OPCGPIO).

**WARNING 47, 24 V supply low:**

The external 24 V DC backup power supply may be overloaded, otherwise Contact your GE supplier.

**WARNING 48, 1.8 V supply low:**

Contact your GE supplier.

**WARNING 49, Speed limit:**

The speed is not within the specified range in par. F-18 Motor Speed Low Limit [RPM] and par. F-17 Motor Speed High Limit [RPM].

**ALARM 50, Auto Tune calibration failed:**

Contact your GE supplier.

**ALARM 51, Auto Tune check Unom and Inom:**

The setting of motor voltage, motor current, and motor power are set set correctly. Please check parameters (P-##).

**ALARM 52, Auto Tune low Inom:**

The motor current is too low. Check the settings.

**ALARM 53, Auto Tune motor too big:**

The motor is too big for the Auto Tune to be carried out.

**ALARM 54, Auto Tune motor too small:**

The motor is too small for the Auto Tune to be carried out.

**ALARM 55, Auto Tune par. out of range:**

The motor parameter values set for the motor are outside acceptable range.

**ALARM 56, Auto Tune interrupted by user:**

The Auto Tune has been interrupted by the user.

**ALARM 57, Auto Tune timeout:**

Try to start the Auto Tune again a number of times, until the Auto Tune is carried out. Please note that repeated runs may heat the motor to a level where the resistance Rs and Rr are increased. In most cases, however, this is not critical.

**ALARM 58, Auto Tune internal fault:**

Contact your GE supplier.

**WARNING 59, Current limit:**

The current is higher than the value in par. F-43 Current Limit.

**WARNING 61, Tracking Error:**

An error has been detected between calculated speed and speed measurement from feedback device. The function Warning/Alarm/Disabling setting is in par. H-20 Motor Feedback Loss Function. Accepted error setting in par. H-21 Motor Feedback Speed Error and the allowed time the error occurs setting in par. H-22 Motor Feedback Loss Timeout. During a commissioning procedure the function may be effective.

**WARNING 62, Output Frequency at Maximum Limit:**

The output frequency is higher than the value set in par. F-03 Max Output Frequency 1

**ALARM 63, Mechanical Brake Low:**

The actual motor current has not exceeded the "release brake" current within the "Start delay" time window.

**WARNING 64, Voltage Limit:**

The load and speed combination demands a motor voltage higher than the actual DC link voltage.

**WARNING/ALARM/TRIP 65, Control Card Over Temperature:**

Control card over temperature: The cut-out temperature of the control card is 80° C.

**WARNING 66, Heatsink Temperature Low:**

The heat sink temperature is measured as 0° C. This could indicate that the temperature sensor is defect and thus the fan speed is increased to the maximum in case the power part or control card is very hot.

**ALARM 67, Option Module Configuration has Changed:**

One or more options modules have either been added or removed since the last power down.

**ALARM 68, Safe Stop:**

Safe Stop has been activated. To resume normal operation, apply 24 V DC to terminal # 37., then send a reset signal (via Bus, Digital I/O, or by pressing [RESET]).

**WARNING 68, Safe Stop:**

Safe Stop has been activated. Normal operation is resumed when Safe Stop is disabled. Warning: Automatic Restart!

**ALARM 70, Illegal Drive Configuration:**

Actual combination of control board and power board is illegal.

**ALARM 71, 1 Safe Stop:**

Safe Stop has been activated from external source. Normal operation can be resumed when 24V dc is applied to terminal # 37. When that happens, a reset signal must be sent (via Bus, Digital I/O, or by pressing [RESET]).

**WARNING 71, Safe Stop:**

Safe Stop has been activated from external source. Normal operation can be resumed when 24V dc is applied to terminal # 37.. Warning: Automatic Restart.

**ALARM 72, Dangerous Failure:**

Safe Stop with Trip Lock. Unexpected signal levels on Safe Stop.

**ALARM 80, Drive Restored to Factory Settings:**

Parameter settings are restored to factory settings after a manual (three-finger) reset.

**ALARM 90, Encoder loss:**

Check the connection to encoder option and eventually replace the OPCENC or MCB 103.

**ALARM 91, Analogue Input 54 Wrong Settings:**

Switch S202 has to be set in position OFF (voltage input) when a KTY sensor is connected to analogue input terminal 54.

**ALARM 250, New Spare Part:**

The power or Switch Mode Power Supply has been exchanged. The frequency converter model number must be restored in the EEPROM. Remember to select 'Save to EEPROM' to complete.

**ALARM 251, New Model Number:**

The Frequency Converter has got a new model number.



## Index

### A

Abbreviations	4
Accel Time 1	40
Access To Control Terminals	25
Alarm Messages	83
Analog Inputs	78
Analog Output	79
Approvals	3
Auto Tune	32, 44

### B

Base Frequency	39
Brake Control	87

### C

Cable Lengths And Cross Sections	80
Cable Lengths And Cross Sections-continued	81
Connection To Mains	17
Control Cables	30
Control Cables	29
Control Card Performance	81
Control Card, +10 V Dc Output	79
Control Card, 24 V Dc Output	79
Control Card, Rs 485 Serial Communication	79
Control Card, Usb Serial Communication	80
Control Characteristics	81
Control Terminals	26
Cooling	41
Cooling Conditions	14

### D

Dc Backup	3
Dc Link	86
Dct 10	3
Decel Time 1	41
Decoupling Plate	19
Devicenet	3
Digital Inputs:	77
Digital Output	79
Disposal Instruction	5

### E

Electrical Installation	26, 29
Electrical Terminals	29
Electronic Overload	87
Electronic Overload	41

### F

Frequency Setting 1	40
Fuses	22

### G

General Warning	6
Graphical Display	37

### I

Intermediate Circuit	86
Ip21 / Nema 1 Kit	3



## K

Kty Sensor

87

## L

Language

39

Language Package 1

0 , 0

Language Package 2

0

Language Package 3

0

Language Package 4

0

Leakage Current

6

Leds

37

## M

Main Reactance

0

Mains Supply

69, 74, 75, 76

Mains Supply (I1, I2, I3)

77

Mechanical Brake Control

34

Mechanical Dimensions

10

Mechanical Mounting

14

Motor Connection

19

Motor Current

40

Motor Name Plate

32

Motor Output

77

Motor Power [hp]

39

Motor Power [kw]

39

Motor Protection

41, 81

Motor Rated Voltage

39

Motor Speed Unit

39

Motor Thermal Protection

34

## N

Name Plate Data

32

Non UI Compliance

22

## O

Output Performance (u, v, w)

77

## P

Panel Through Mounting

15

Parallel Connection Of Motors

34

Potentiometer Reference

28

Profibus

3

Protection

22

Protection And Features

81

Pulse Start/stop

27

Pulse/encoder Inputs

79

## R

Reference Site, 3-13

40

Relay Outputs

80

Removal Of Knockouts For Extra Cables

16

Repair Work

7

Residual Current Device

6

## S

Safe Stop

7

Safety Precautions

6

Screened/armoured

30

Serial Communication

80

Speed Up/down

28

Start/stop

27



Stator Leakage Reactance	0
Status Messages	37
Surroundings	81
Switches S201, S202, And S801	31
Symbols	4

**T**

Thermistor	41
Torque Characteristics	77

**U**

Unintended Start	7
------------------	---

**V**

Voltage Level	77
Voltage Reference Via A Potentiometer	28

**W**

Warnings	83
----------	----

The instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the GE company.

AF-650 GP is a trademark of the General Electric Company.

GE Consumer & Industrial  
41 Woodford Avenue  
Plainville, CT 06062

[www.geelectrical.com/drives](http://www.geelectrical.com/drives)



imagination at work

130R0356

MG34F102



DET-607